

Prepared by: TECHNIKON LLC 5301 Price Avenue 🔻 McClellan, CA, 95652 🔻 (916) 929-8001 www.technikonllc.com

> US Army Contract DAAE30-02-C-1095 **FY 2003 Tasks**

Emission Comparison of PCS Parting Spray

Greensand Systems *Hill & Griffith SLIKEASE*®

Technikon # 1410-111 FJ

14 October 2003 (This report revised for public distribution)







DAIMLERCHRYSLER Find Meter Company, General Motors,





this page intentionally left blank

Emission Comparison of PCS Parting Spray Greensand Systems

1410-1.1.1 FJ

This report has been reviewed for completeness and accuracy and approved for release by the following:

Research Che mist	// Original Signed // Carmen Hornsby	Date
Process Engineering Manager	// Original Signed //	Zaie
	Steven M. Knight	Date
V.P. Measurement Technology	// Original Signed // Clifford R Glowacki, CIH	Date
V.P. Operations	// Original Signed // George Crandell	Date
President	// Original Signed // William Walden	Date

The data contained in this report were developed to assess the relative emissions profile of the product or process being evaluated against a standardized baseline process profile. You may not obtain the same results in your facility. Data was not collected to assess casting quality, cost, or producibility.

this page intentionally left blank

Table of Contents

Executive	Summary1
1.0	Introduction
1.1	Background
1.2	Technikon Objectives
1.3	Report Organization
1.4	Specific Test Plan and Objectives
2.0	Test Methodology
2.1	Description of Process and Testing Equipment5
2.2	Description of Testing Program
2.3	Quality Assurance and Quality Control (QA/QC) Procedures
3.0	Test Results9
4.0	Discussion of Results

List of Figures

Figure 2-1	Pre-Production Foundry Layout Diagram	5
Figure 3-1	Emission Indicators from Test Series FI and FJ – Lb/Tn Metal	13
Figure 3-2	Selected HAP Emissions from Test Series FI and FJ – Lb/Tn Metal	13
Figure 3-3	Selected VOC Emissions from Test Series FI and FJ – Lb/Tn Metal	14
Figure 3-4	Emission Indicators from Test Series FI and FJ – Lb/Lb Parting Spray	14
Figure 3-5	Selected HAP Emissions from Test Series FI and FJ – Lb/Lb Parting Spray	15
Figure 3-6	Selected VOC Emissions from Test Series FI and FJ - Lb/Lb Parting Spray	15

List of Tables

Table 1-1	Test Plan Summary	4
Table 2-1	Process Parameters Measured	7
Table 2-2	Sampling and Analytical Methods	7
Table 3-1	Summary of Test Plans FI and FJ Average Results - Lb/Tn Metal 1	0
Table 3-2	Summary of Test Plans FI and FJ Average Results - Lb/Lb Parting Spray 1	1
Table 3-3	Summary of Test Plans FI and FJ Average Process Parameters	2

Appendices

Appendix A	Approved Test Plans and Sample Plans for Test Series FI and FJ	19
Appendix B	Test Series FI and FJ Detailed Emission Results	49
Appendix C	Test Series FI and FJ Detailed Process Data	69
Appendix D	Method 25A Charts	73
Appendix E	Glossary	81

Executive Summary

This report contains the results of emission testing to evaluate the pouring, cooling, and shakeout emissions from Test FJ, a coreless greensand system without seacoal, using a vegetable oil-based liquid parting spray release agent. These data are compared to results from Test FI, a baseline using a standard parting spray system. All testing was conducted by Technikon, LLC in its Pre-Production foundry. The emissions results are reported in both pounds of analyte per ton of metal poured and pounds of analyte per pound of parting spray used.

The testing performed involved the collection of continuous air samples over a seventy-five minute period, including the mold pouring, cooling, shakeout, and post shakeout periods. Process and stack parameters were measured and include: the weights of the casting, mold, and parting spray; Loss on Ignition (LOI) values for the mold prior to the test; metallurgical data; and stack temperature, pressure, volumetric flow rate and moisture content. The process parameters were maintained within prescribed ranges in order to ensure the reproducibility of the tests runs. Samples were collected and analyzed for sixty-six (66) target compounds using procedures based on US EPA Method 18. Continuous monitoring of the Total Gaseous Organic Concentration (TGOC) of the emissions was conducted according to US EPA Method 25A.

The mass emission rate of each parameter or target compound was calculated using the Method 25A data or the laboratory analytical results, the measured source data, the weight of parting spray used and the weight of each casting. Results for structural isomers have been grouped and reported as a single entity. For example, ortho-, meta-, and para-xylene are the three (3) structural isomers of dimethyl benzene. The separate isomer results are available in Appendix B of this report. Other "emissions indicators," in addition to the TGOC as Propane, were also calculated. The HC as Hexane results represent the sum of all organic compounds detected and expressed as Hexane. All of the following sums are sub-groups of this measure. The "Sum of VOCs" is based on the sum of the individual target VOCs measured and includes the selected HAPs and selected Polycyclic Organic Material (POMs) listed in the Clean Air Act Amendments of 1990. The "Sum of HAPs" is the sum of the individual target HAPs measured and includes the selected POMs. Finally, the "Sum of POMs" is the sum of all of the polycyclic organic material measured.

Results for the emission indicators are shown in the following tables reported as lbs/tn of metal and lbs/lb of parting spray.

	TGOC as Propane	HC as Hexane	Sum of VOCs	Sum of HAPs	Sum of POMs
Test FI (baseline)	0.8651	0.1680	0.0819	0.0643	0.0030
Test FJ	0.7371	0.1179	0.0823	0.0724	0.0030

Test Plans Fl and FJ Emissions Indicators – Lb/Tn Metal

	TGOC as Propane	HC as Hexane	Sum of VOCs	Sum of HAPs	Sum of POMs
Test FI (baseline)	0.4717	0.0895	0.0455	0.0358	0.0018
Test FJ	0.3930	0.0620	0.0440	0.0387	0.0016

Test Plans Fl and FJ Emissions Indicators – Lb/Lb Parting Spray

It must be noted that the results from the reference and product testing performed are not suitable for use as emission factors or for other purposes other than evaluating the <u>relative emission reductions</u> associated with the use of alternative materials, equipment, or manufacturing processes. The emissions measurements are unique to the specific castings produced, materials used, and testing methodology associated with these tests. These measurements <u>should not</u> be used as the basis for estimating emissions from actual commercial foundry applications.

1.0 Introduction

1.1 Background

Technikon LLC is a privately held contract research organization located in McClellan, California, a suburb of Sacramento. Technikon offers emissions research services to industrial and government clients specializing in the metal casting and mobile emissions areas. Technikon operates the Casting Emission Reduction Program (CERP). CERP is a cooperative initiative between the Department of Defense (US Army) and the United States Council for Automotive Research (USCAR). Its purpose is to evaluate alternative casting materials and processes that are designed to reduce air emissions and/or produce more efficient casting processes. Other technical partners directly supporting the project include: the American Foundry Society (AFS); the Casting Industry Suppliers Association (CISA); the US Environmental Protection Agency (US EPA); and the California Air Resources Board (CARB).

1.2 Technikon Objectives

The primary objective of Technikon is to evaluate materials, equipment, and processes used in the production of metal castings. Technikon's facility was designed to evaluate alternate materials and production processes designed to achieve significant air emission reductions, especially for the 1990 Clean Air Act Amendment. The facility has two principal testing arenas: a Pre-Production Foundry designed to measure airborne emissions from individually poured molds, and a Production Foundry designed to measure air emissions in a continuous full scale production process. Each of these testing arenas has been specially designed to facilitate the collection and evaluation of airborne emissions and associated process data.

The Production Foundry provides simultaneous detailed individual emission measurements using methods based on US EPA protocols for the melting, pouring, sand preparation, mold making, and core making processes.

It must be noted that the reference and product testing performed is not suitable for use as emission factors or for purposes other than evaluating the <u>relative emission</u> reductions associated with the use of alternative materials, equipment, or processes. The emissions measurements are unique to the specific castings produced, materials used, and testing methodology associated with these tests, and should not be used as the basis for estimating emissions from actual commercial foundry applications.

1.3 Report Organization

This report has been designed to document the methodology and results of a specific test plan that was used to evaluate VOC emissions from a coreless greensand system. Section 2 of this report includes a summary of the methodologies used for data collection and analysis, emission calculations, QA/QC procedures, and data management and reduction methods. Specific data collected during this test are summarized in Section 3 of this report, with detailed data included in Appendix B of this report. Section 4 of this report contains a discussion of the results.

The raw data for this test series are included in a data binder that is maintained at the Technikon facility.

1.4 Specific Test Plan and Objectives

Table 1-1 provides a summary of the test plans. The details of the approved test plans are included in Appendix A.

	Test Plan	Test Plan	
Type of Process tested	Pattern Spray Greensand Baseline	Pattern Spray Greensand Product Test	
Test Plan Number	1410 121 FI	1410 111 FJ	
Parting Spray System	H & G Y-250	H & G SLIKEASE [®]	
Metal Poured	Iron	Iron	
Casting Type	4-on Star	4-on Star	
Number of molds poured	9	9	
Test Dates	7/14/03 > 7/17/03	7/29/03 > 7/31/03	
Emissions Measured	TGOC as Propane, HC as Hexane, 66 Organic HAPs and VOCsTGOC as Propane, HC as Hexar 66 Organic HAPs and VOCs		
Process Parameters Measured	Total Casting, Mold, and Parting Spray Weights; Metallurgical data, % LOI; Stack Temperature, Moisture Content, Sand Temperature, Pressure, and Volumetric Flow Rate	Total Casting, Mold, and Parting Spray Weights; Metallurgical data, % LOI; Stack Temperature, Moisture Content, Sand Temperature, Pressure, and Volumetric Flow Rate	

Table 1-1Test Plan Summary

2.0 Test Methodology

2.1 Description of Process and Testing Equipment

Figure 2-1 is a diagram of the Pre-Production Foundry process equipment.





Figure 2-1 Pre-Production Foundry Layout Diagram

2.2 Description of Testing Program

The specific steps used in this sampling program are summarized below:

1. <u>Test Plan Review and Approval:</u> The proposed test plan was reviewed and approved by the Technikon staff.

2. <u>Mold and Metal Preparation</u>: The 4-on star greensand (without seacoal) molds are prepared to a standard composition by the Technikon production team. The parting spray is applied to the mold pattern at approximately forty (40) grams per mold. Iron is melted in a 1000 lb. Ajax induction furnace. The amount of metal melted is determined from the poured weight of the casting and the number of molds to be poured. The metal composition is prescribed by a metal composition worksheet. The weight of metal poured into each mold is recorded on the process data summary sheet.





Total Enclosure Test Stand

3. <u>Individual Sampling Events:</u> Replicate tests are performed on nine (9) mold packages. The mold packages are placed into an enclosed test stand heated to approximately 85°F. Iron is poured through an opening in the top of the emission enclosure.

Continuous air samples are collected during the forty-five minute pouring and cooling process, during the fifteen minute shakeout of the mold, and for an additional fifteen minute period following shakeout. The total sampling time is seventy-five minutes.



Method 25A (TGOC) and Method 18 Sampling Train

4. <u>Process Parameter Measurements:</u> Table 2-1 lists the process parameters that are monitored during each test. The analytical equipment and methods used are also listed.

Parameter	Analytical Equipment and Methods
Mold Weight	Acme 4260 Crane Scale (Gravimetric)
Casting Weight	Westweigh PP2847 Platform Scale (Gravimetric)
Binder Weight	Mettler PJ8000 Digital Scale (Gravimetric)
Volatiles	Mettler PB302 Scale (AFS Procedure 2213-00-S)
LOI, % at Mold and Shakeout	Denver Instruments XE-100 Analytical Scale (AFS procedure 5100-00-S)
Metallurgical Parameters	
Pouring Temperature	Electro-Nite DT 260 (T/C Immersion Pyrometer)
Carbon/Silicon Fusion Temperature	Electro-Nite Datacast 2000 (Thermal Arrest)
Alloy Weights	Ohaus MP2 Scale
Mold Compactability	Dietert 319A Sand Squeezer (AFS Procedure 2221-00-S)

Table 2-1	Process Parameters Measured
-----------	-----------------------------

5. <u>Air Emissions Analysis:</u> The specific sampling and analytical methods used in the Pre-Production Foundry tests are based on the US EPA reference methods shown in Table 2-2. The details of the specific testing procedures and their variance from the reference methods are included in the <u>Technikon Standard Operating Procedures</u>.

Table 2-2	Sampling and Analytical Methods
-----------	---------------------------------

Measurement Parameter	Test Method
Port Location	EPA Method 1
Number of Traverse Points	EPA Method 1
Gas Velocity and Temperature	EPA Method 2
Gas Density and Molecular Weight	EPA Method 3a
Gas Moisture	EPA Method 4, gravimetric
HAPs Concentration	EPA Method 18, TO11
VOCs Concentration	EPA Method 18, 25A, TO11

*These methods were specifically modified to meet the testing objectives of the CERP Program.

6. Data Reduction, Tabulation and Preliminary Report Preparation: The analytical results of the emissions tests provide the mass of each analyte in the sample. The total mass of the analyte emitted is calculated by multiplying the mass of analyte in the sample times the ratio of total stack gas volume to sample volume. The total stack gas volume is calculated from the measured stack gas velocity and duct diameter, and corrected to dry standard conditions using the measured stack pressures, temperatures, gas molecular weight and moisture content. The total mass of analyte is then divided by the weight of the parting spray and/or the weight of the casting used to provide emissions data in pounds of analyte per pound of parting spray and pounds of analyte per ton of metal.

The results of each of the sampling events are included in Appendix B of this report. The results of each test are also averaged and are shown in Tables 3-1 and 3-2.

7. **<u>Report Preparation and Review</u>**: The Preliminary Draft Report is reviewed by the Process Team and Emissions Team to ensure its completeness, consistency with the test plan, and adherence to the prescribed QA/QC procedures. Appropriate observations, conclusions and recommendations are added to the report to produce a Draft Report. The Draft Report is reviewed by the Vice President-Measurement Technologies, the Vice President-Operations, the Manager-Process Engineering, and the Technikon President. Comments are incorporated into a draft Final Report prior to final signature approval and distribution.

2.3 Quality Assurance and Quality Control (QA/QC) Procedures

Detailed QA/QC and data validation procedures for the process parameters, stack measurements, and laboratory analytical procedures are included in the <u>Technikon Emissions Testing and Analytical Testing Standard Operating Procedures</u>. In order to ensure the timely review of critical quality control parameters, the following procedures are followed:

- Immediately following the individual sampling events performed for each test, specific process parameters are reviewed by the Manager - Process Engineering to ensure that the parameters are maintained within the prescribed control ranges. Where data are not within the prescribed ranges, the Manager - Process Engineering and the Vice President - Operations determine whether the individual test samples should be invalidated or flagged for further analysis following review of the laboratory data.
- The source (stack) and sampling parameters, analytical results and corresponding laboratory QA/QC data are reviewed by the Emissions Measurement Team to confirm the validity of the data. The VP-Measurement Technologies reviews and approves the recommendation, if any, that individual sample data should be invalidated. Invalidated data are not used in subsequent calculations.

3.0 Test Results

The average emission results, in pounds per ton of metal poured and pounds per pound of parting spray, are presented in Tables 3-1 and 3-2 respectively. The tables include the individual target compounds that comprise at least 95% of the total VOCs measured, along with the corresponding Sum of VOCs, Sum of HAPs, and Sum of POMs. The tables also include the TGOC as propane, HC as hexane, methane, and carbon dioxide.

Figures 3-1 to 3-3 present the five emissions indicators and selected individual HAP and VOC emissions data from Table 3-1 in graphical form. Figures 3-4 to 3-6 present the five emission indicators and selected individual HAP and VOC emissions data from Table 3-2. The percentage change in emissions for this test compared to the baseline is shown in Table 3-1.

Appendix B contains the detailed data including the results for all analytes measured. Table 3-3 includes the averages of the key process parameters. Detailed process data are presented in Appendix C.

Method 25A charts for the tests are included in Appendix D of this report. The charts are presented to show the VOC profile of emissions for each pour.

Table 3-1 Summary of Test Plans Fl and FJ Average Results – Lb/Tn Metal

Analytes	Test FI (Lb/Tn Metal)	Test FJ (Lb/Tn Metal)	% Change from Test FI								
TGOC as Propane	0.8651	0.7371	-15								
HC as Hexane	0.1680	0.1179	-30								
Sum of VOCs	0.0819	0.0823	0								
Sum of HAPs	0.0643	0.0724	13								
Sum of POMs	0.0030	0.0030	0								
Indivi	dual Organic	: HAPs									
Benzene	0.0304	0.0410	35								
Toluene	0.0106	0.0103	-3								
o,m,p-Xylene	0.0095	0.0079	-17								
Acetaldehyde	0.0030	0.0033	10								
Naphthalene	0.0023	0.0025	9								
Hexane	0.0023	0.0016	-30								
Formaldehyde	0.0018	0.0014	-22								
Ethylbenzene	0.0015	0.0014	-7								
Styrene	0.0010	0.0015	50								
Methylnaphthalenes	0.0008	0.0004	-50								
	Other VOCs	5									
Trimethylbenzenes	0.0044	0.0030	-32								
Heptane	0.0044	0.0018	-59								
Tetradecane	0.0029	0.0003	-90								
Octane	0.0022	0.0018	-18								
Ethyltoluenes	0.0018	0.0010	-44								
Indene	0.0007	0.0012	71								
(Other Analytes										
Carbon Dioxide	18.72	18.99	1								
Methane	0.0306	0.0334	9								

Individual results constitute >95% of mass of all detected VOCs.

All "Other Analytes" are not included in the sum of HAPs or VOCs.

"Percent Change from Test FI" values in bold have a 95% probability that the differences in the average values were not from test variability.

Background Methane and Carbon Dioxide were found at 0.0429 and 22.66 Lb/Tn Metal respectively, and Carbon Monoxide was found at the reporting limit (0.3 Lb/Tn Metal).

Table 3-2Summary of Test Plans Fl and FJ Average Results – Lb/Lb Parting
Spray

Analytes	Test FI (Lb/Lb Part- ing Spray)	Test FJ (Lb/Lb Part- ing Spray)									
TGOC as Propane	0.4717	0.3930									
HC as Hexane	0.0895	0.0620									
Sum of VOCs	0.0455	0.0440									
Sum of HAPs	0.0358	0.0387									
Sum of POMs	0.0018	0.0016									
Individual Organic HAPs											
Benzene	0.0167	0.0220									
Toluene	0.0058	0.0055									
o,m,p-Xylene	0.0052	0.0042									
Acetaldehyde	0.0016	0.0017									
Hexane	0.0014	0.0008									
Naphthalene	0.0013	0.0014									
Formaldehyde	0.0010	0.0007									
Ethylbenzene	0.0008	0.0008									
Styrene	0.0005	0.0008									
Methylnaphthalenes	0.0005	0.0002									
Other	· VOCs										
Trimethylbenzenes	0.0024	0.0016									
Heptane	0.0024	0.0010									
Tetradecane	0.0017	0.0002									
Octane	0.0012	0.0010									
Ethyltoluenes	0.0010	0.0005									
Indene	0.0004	0.0006									
Other	Analytes										
Methane	0.0168	0.0178									
Carbon Dioxide	10.29	10.11									

Individual results constitute >95% of mass of all detected VOCs. All "Other Analytes" are not included in the sum of HAPs or VOCs.

Background Methane and Carbon Dioxide were found at 0.0201 and 11.82 Lb/Lb Parting Spray respectively. Carbon Monoxide was found at the reporting limit (0.2 Lb/Lb Parting Spray).

Table 3-3 Summary of Test Plans Fl and FJ Average Process Parameters

No Coal Greensand PCS Pattern Spray Tests	Test FI	Test FJ
Cast Weight- All Metal Inside Mold (lbs.)	97.9	96.2
Pouring Time (sec.)	17	19
Pouring Temp (°F)	2682	2685
Pour Hood Process Air Temp at Start of Pour (°F)	88	88
Muller Batch Weight (lbs.)	902	897
GS Mold Sand Weight (lbs.)	658	663
Mold Compactability (%)	48	44
Mold Temperature (°F)	89	89
Average Green Compression (psi)	13.58	13.52
GS Compactability (%)	44	38
GS Moisture Content (%)	1.92	1.82
GS Clay Content (%)	6.94	7.33
1800°F LOI - Mold Sand (%)	1.11	1.01
900°F Volatiles (%)	0.39	0.45
Liquid Parting Spray (grams)	40.6	40.9






Figure 3-1 Emission Indicators from Test Series Fland FJ – Lb/Tn Metal




















Figure 3-6 Selected VOC Emissions from Test Series FI and FJ – Lb/Lb Parting Spray



this page intentionally left blank

4.0 Discussion of Results

The sampling and analytical methodologies were the same for Test Plans FI and FJ.

Observation of measured process parameters indicates that the tests were run within an acceptable range. In Tables 3-1 and 3-2, the "% Change from Test FI" emissions values presented in **bold** letters have a greater than 95% probability that the differences in the average values were not the result of variability in the test protocol determined from T-Statistic calculations. Tables showing the T-Statistics calculated are found in Appendix B.

The results of the tests performed for the comparison of Test FI to Test FJ show a **15%** reduction in TGOC (THC) as propane, a **32%** reduction in HC as hexane, a **0%** change in Sum of VOCs, a **13%** increase in Sum of HAPs, and a **0%** change in Sum of POMs when expressed in pounds per ton of metal. Benzene was found to be the largest contributor to the total HAPs and VOCs for both Tests FI and FJ and a **35%** increase in benzene was found for Test FJ compared to the baseline Test FI.

Carbon dioxide and methane were detected in the ambient (blank) samples for both Tests FJ and FI. Carbon monoxide was found at the reporting limit in the ambient sample for Test FJ but was not found in any of the test samples for either Test FJ or FI.

Two methods were employed to measure undifferentiated hydrocarbon emissions, TGOC (THC) as propane, performed in accordance with EPA Method 25A, and HC as hexane. EPA Method 25A, TGOC (as propane), is weighted to the detection of more volatile hydrocarbon species, beginning at C1 (methane), with results calibrated against a three-carbon alkane (propane). HC as hexane is weighted to the detection of relatively less volatile compounds. This method detects hydrocarbon compounds in the alkane range between C6 and C16, with results calibrated against a six-carbon alkane (hexane).

Target analyte reporting limits expressed in both pounds per ton of metal and pounds per pound of parting spray are shown in Appendix B.

this page intentionally left blank

APPENDIX A APPROVED TEST PLANS AND SAMPLE PLANS FOR TEST SERIES FI AND FJ

this page intentionally left blank

TECHNIKON TEST PLAN

- > CONTRACT NUMBER: <u>1410</u> TASK NUMBER: <u>1.2.1</u> Series: <u>FI</u>
- > SAMPLE EVENTS: Estimated 9
- > SITE: X PRE-PRODUCTION ____ FOUNDRY
- > **TEST TYPE:** <u>Pattern spray greensand baseline</u>
- > METAL TYPE: <u>Class 30 gray iron</u>
- > MOLD TYPE: 4-on coreless star greensand with no seacoal and petroleum oil liquid parting
- > NUMBER OF MOLDS: 9 + pattern spray conditioning.
- > CORE TYPE: <u>None</u>
- > **TEST DATE:** START: 07 July 2003

FINISHED: 18 July 2003

TEST OBJECTIVES:

Create Pouring, Cooling, and Shakeout emissions baseline for liquid parting with coal-less greensand mix. Results shall be reported as pounds of emission/pound of liquid parting and pounds of emission /ton of metal poured.

VARIABLES:

The pattern will be the 4-on star. The mold will be made with Wexford W450 sand, 7% western and southern bentonite in a 5:2 ratio, no seacoal, tempered to 40-45% compactability, mechanically compacted. An oil based liquid parting H&G Y-250 will be used. The molds will be maintained at 80-90°F prior to pouring. The sand heap will be maintained at 900 pounds. Molds will be poured with iron at 2680 +/- 10° F. Mold cooling will be 45minutes follow by 15 minutes of shakeout, or until no more material remains to be shaken out. The initial process air temperature will be maintained at 85-90°F. Emission testing will be 75 minutes.

BRIEF OVERVIEW:

The 4 on star pattern is a new test pattern that will be used as a baseline for pattern release agent product comparisons. The new Osborn Jolt squeeze machine will be an improvement over previously hand rammed molds, which are inherently inconsistent. This test is to establish baseline line emissions for this pattern and the Osborn machine combination with parting oil and no sea-coal.

SPECIAL CONDITIONS:

The process will include rigorous maintenance of the size of sand heap and maintenance of the material and testing environmental temperatures to reduce seasonal and daily temperature-dependent influence on the emissions

Process Engineering Manager (Technikon)	Date	
V.P. Measurement Technology (Technikon)	Date	
V.P. Operations (Technikon)	Date	
Test Design Committee Representative	Date	
Emission Committee Representative	Date	

Series FI

PCS Pattern Spray Baseline with No-coal Greensand & Mechanized Molding Process Instructions

A. Experiment:

- **1.** Create an emission baseline for pattern spray.
 - **a.** The molds shall be started with all virgin Wexford W450 sand, bonded with 7% Western & Southern Bentonite in the ratio of 5:2.
 - **b.** The molds shall be tempered with potable water to 40-45% compactability, poured at constant weight, temperature, surface area, & shape factor. This test will recycle the same mold material, replacing burned clay with new materials after each casting cycle.
- **B.** Materials:
 - 1. Mold sand: Virgin mix of Wexford W450 lake sand, western and southern bentonites in ratio of 5:2, and potable water per recipe. No seacoal.
 - 2. Core: None
 - **3.** Metal: Class 30-35 gray cast iron poured at 2680°F.
 - 4. Pattern Spray: H&G Y-250 petroleum based.

Caution: Observe all safety precautions attendant to these operations as delineated in the Preproduction operating and safety instruction manual.

- **5.** The following test shall be conducted:
 - **a.** Sand batch: Single sand batch to be used for all FI molds.
 - **b.** The recycled sand heap shall be maintained at 900+-10 pounds
 - c. FI001: Virgin mix as described above, un-vented mold.
 - d. FI002-FI0XX: Re-mulled, reconstituted greensand, potable water, un-vented molds.
 - e. 20 grams of H&G Y-250 parting spray shall be brushed on each mold half.
 - **f.** Emission absorption tube sampling will begin after THC determination of stability of parting spray content.
- **C.** Sand preparation
 - 1. Start up batch: make 1, FI001.
 - **a.** Thoroughly clean the pre-production muller elevator and molding hoppers.

- **b.** Weigh and add 1225 +/- 10 pounds of new Wexford W450 Lakesand, per the recipe, to the running pre-production muller.
- **c.** Add 5 pounds of potable to the muller to suppress dust distributing it across the sand. Allow to mix for 1 minute.
- **d.** Add the clays slowly to the muller to allow them to be distributed throughout the sand mass in proportion to the sand weight per the recipe for this test.
- e. Dry mull for about 3 minutes to allow distribution and some grinding of the clays to occur.
- **f.** Temper the sand-clay mixture slowly, with potable water, to allow for distribution.
- **g.** After about 2 gallons of water have been added allow 30 seconds of mixing then start taking compactability test samples.
- **h.** Based on each test add water incrementally to adjust the temper. Allow 1 minute of mixing. Retest. Repeat until the compactability is in the range 40-45%.
- i. Discharge the sand into the mold station elevator.
- **j.** Grab sufficient sample after the final compactability test to fill a quart zip-lock bag. Label bag with the test series and sequence number, date, and time of day and deliver it immediately to the sand lab for analysis
- **k.** Record the total sand mixed in the batch, the total of each type of clay added to the batch, the amount of water added, the total mix time, the final compactability and sand temperature at charge and discharge.
- The sand will be immediately characterized for Methylene Blue Clay, Moisture content, Compactability, Green Compression strength, 1800°F loss on ignition (LOI), and 900°F volatiles. Each volatile and LOI test requires a separate 50 gram sample from the collected sand.
- **m.** Empty the extra greensand from the mold hopper into a clean empty dump hopper whose tare weight is known. Set this sand aside to be used to maintain the recycled batch at 900+/-10 pounds
- **2.** Re-mulling: FI002
 - **a.** Add to the sand recovered from poured mold FI001sufficient pre-blended sand so that the sand batch weight is 900 +/- 10 pounds. Record the sand weight.
 - **b.** Return the sand to the muller and dry blend for about one minute.
 - **c.** Add the clays, as directed by the process engineering staff, slowly to the muller to allow them to be distributed throughout the sand mass.
 - **d.** Add 5 pounds of water to the muller to suppress dust distributing it across the sand. Allow to mix for 1 minute.
 - **e.** Follow the above procedure beginning at B.1.f.
- **3.** Re-mulling: FI003-FI0XX
 - **a.** Add to the sand recovered from the previous poured mold, mold machine spill sand, the residual mold hopper sand and sufficient pre-blended sand to total 900 +/- 10 pounds.
 - **b.** Return the sand to the muller and dry blend for about one minute.

- **c.** Add the clays, as directed by the process engineering staff, slowly to the muller to allow them to be distributed throughout the sand mass.
- **d.** Add 5 pounds of water to the muller to suppress dust distributing it across the sand. Allow to mix for 1 minute.
- e. Follow the above procedure beginning at B.1.f.
- **D.** Molding: 4- on star pattern.
 - **1.** Pattern preparation:
 - **a.** Inspect and tighten all loose pattern and gating pieces.
 - **b.** Repair any damaged pattern or gating parts.
 - 2. Mount the drag 4-on star pattern with gating into the mold machine bolster and bolt it down tightly.
 - **a.** Weigh a 500 ml beaker, 200 ml of H&G Y-250 parting spray and a 1-inch brush immersed in the parting spray.
 - **b.** Incrementally brush parting spray evenly over each side of the entire pattern until the gross weight of the beaker, residual parting spray, and the immersed brush are twenty (20) grams lighter that in C.2.a.
 - **c.** Repeat for the other side of the pattern in turn.
 - d. Repeat C.2.b-c for each mold cycle.
 - **3.** Mount a cope follower board containing a pour cup pattern to the underside of the squeeze head plate.
 - 4. Check the alignment of the pour cup by manually raising the table using the squeeze bypass valve at the bottom rear of the machine until the sprue pierces the pour cup pattern. Move the pour cup pattern as necessary.
 - 5. Remove the sprue if making a mold drag half. Leave it attached if making a cope half.
 - 6. Use the overhead crane to place the pre-weighed drag/cope flask on the mold machine table, parting line surface down.
 - 7. Locate a 24 x 24 x4 inch deep wood upset on top of the flask.
 - 8. Make the green sand mold on the Osborn Whisper Ram Jolt-Squeeze mold machine

WARNING: Only properly trained personnel may operate this machine. Proper personal protective equipment must be worn at all times while operating this equipment, including safety glasses with side shields and a properly fitting hard hat. Industrial type boots are highly recommended.

WARNING: Stand clear of the mold machine table and swinging head during the following operation or serious injury or death could result.

a. Open the air supply to the mold machine.

WARNING: The squeeze head may suddenly swing to the outboard side or forward. Do not stand in the outer corners of the molding enclosure.

- **b.** On the operator's panel turn the POWER switch to ON.
- **c.** Turn the RAM-JOLT-SQUEEZE switch to ON.
- **d.** Turn the DRAW UP switch to AUTO
- e. Set the PRE-JOLT timer to 4-5 seconds.
- **f.** Set the squeeze timer to 8 seconds.
- **g.** Manually riddle a half to one inch or so of sand on the pattern using a ¹/₄ inch mesh riddle. Source the sand from the overhead mold sand hopper by actuating the CHATTER GATE valve located under the operators panel.
- **h.** Fill the 24 x 24 x 10 inch flask and the upset with greensand from the overhead molding hopper.
- **i.** Manually level sand in the upset. By experience manually adjust the sand depth so that the resulting compacted mold is fractionally above the flask only height.

WARNING: Failure to stand clear of the molding table and flasks in the following operations could result in serious injury as this equipment is about to move up and down with great force.

j. Initiate the settling of the sand in the flask by pressing the PRE-JOLT push button. Allow this cycle to stop before proceeding.

WARNING: Stand clear of the entire mold machine during the following operations. Several of the machine parts will be moving.

Failure to stand clear could result in severe injury even death.

k. Using both hands initiate the automatic machine sequence by simultaneously pressing and releasing the green push buttons on either side of the operators panel. The machine will squeeze and jolt the sand in the flask and then move the squeeze head to the side.

WARNING: Do no re-approach the machine until the squeeze head has stopped at the side of the machine.

- **I.** Remove the upset and set it aside.
- **m.** Screed the bottom of the mold flat if required.
- **n.** Press and release the LOWER DRAW/STOP push button to separate the flask and mold from the pattern.
- **o.** Use the overhead crane to lift the mold half and remove it from the machine.
- **p.** Finally, press and release the draw down pushbutton to cause the draw frame to return to the start position.
- **9.** If the mold half is a drag, roll it parting line side up, set it on the floor, blow it out, and cover it to keep it clean.
- **10.** Close the cope over the drag being careful not to crush anything.
- **11.** Clamp the flask halves together.
- **12.** Weigh and record the weight of the closed un-poured mold, the pre-weighed flask, and the sand weight by difference

- **13.** Deliver the mold to the previously cleaned shakeout to be poured. Do not cover the mold with the emission hood.
- E. Shakeout.
 - 1. After the cooling time prescribed in the test plan turn on the shakeout unit and run it for until the greensand has passed into the hopper below.
 - 2. Turn off the shakeout, remove the flask with casting, and recover the sand from the hopper and surrounding floor.
 - **3.** Weigh and record the metal poured and the total sand weight recovered and rejoined with the left over mold sand from the molding hopper.
- **F.** Melting:
 - **1.** Initial charge:
 - **a.** Charge the furnace according to the heat recipe.
 - **b.** Place part of the steel scrap on the bottom, followed by carbon alloys, and the balance of the steel.
 - **c.** Place a pig on top on top.
 - **d.** Bring the furnace contents to the point of beginning to melt over a period of 1 hour at reduced power.
 - e. Add the balance of the metallics under full power until all is melted and the temperature has reached 2600 to 2700°F.
 - **f.** Slag the furnace and add the balance of the alloys.
 - **g.** Raise the temperature of the melt to 2700°F and take a DataCast 2000 sample. The temperature of the primary liquidus (TPL) must be in the range of 2200-2350°F.
 - **h.** Hold the furnace at $2500-2550^{\circ}$ F until near ready to tap.
 - i. When ready to tap raise the temperature to 2700° F and slag the furnace.
 - **j.** Record all metallic and alloy additions to the furnace, tap temperature, and pour temperature. Record all furnace activities with an associated time.
 - **2.** Back charging.
 - **a.** Back charge the furnace according to the heat recipe,
 - **b.** Charge a few pieces of steel first to make a splash barrier, followed by the carbon alloys.
 - **c.** Follow the above steps beginning with E.1.e.
- **G.** Emptying the furnace.
 - **1.** Pig the extra metal only after the last emission measurement is complete to avoid contaminating the air sample.
 - 2. Cover the empty furnace with ceramic blanket to cool.
- **H.** Pouring:

- **1.** Preheat the ladle.
 - **a.** Tap 400 pounds more or less of 2700°F metal into the cold ladle.
 - **b.** Casually pour the metal back to the furnace.
 - **c.** Cover the ladle.
 - **d.** Reheat the metal to $2780 + 20^{\circ}$ F.
 - e. Tap 450 pounds of iron into the ladle while pouring inoculating alloys onto the metal stream near its base.
 - **f.** Cover the ladle to conserve heat.
 - g. Move the ladle to the pour position, and wait until the metal temperature reaches $2680 + 10^{\circ}$ F.
 - **h.** Commence pouring keeping the sprue full.
 - i. Upon completion return the extra metal to the furnace, and cover the ladle.

Steven Knight Mgr. Process Engineering

PRE-PRODUCTION FI - SERIES SAMPLE PLAN

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/9/2003											FI CONDITIONING - RUN 1
FI CR-1											
TH	С	х									

PRE-PRODUCTION FI - SERIES SAMPLE PLAN

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/10/2003											FI CONDITIONING - RUN 2
FI CR-2											
THO		х									

PRE-PRODUCTION FI - SERIES SAMPLE PLAN

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/10/2003											FI CONDITIONING - RUN 3
FI CR-3											
THC		х									

PRE-PRODUCTION FI - SERIES SAMPLE PLAN

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/10/2003											FI CONDITIONING - RUN 4
FI CR-4											
THC		х									

PRE-PRODUCTION FI - SERIES SAMPLE PLAN

						1		-		1	
Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/14/2003											
RUN 1											
THC	FI001	Х									TOTAL
M-18	FI00101		1						60	1	Carbopak charcoal
M-18	FI00102				1				0		Carbopak charcoal
M-18 MS	FI00103		1						60	2	Carbopak charcoal
M-18 MS	FI00104			1					60	3	Carbopak charcoal
Gas, CO, CO2	FI00105		1						60	4	Tedlar Bag
Gas, CO, CO2	FI00106				1				0		Tedlar Bag
	Excess								500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FI00107		1						1000	7	100/50 mg Charcoal (SKC 226-01)
NIOSH 1500	FI00108				1				0		100/50 mg Charcoal (SKC 226-01)
	Excess								1000	8	Excess
TO11	FI00109		1						1000	9	DNPH Silica Gel (SKC 226-119)
TO11	FI00110				1				0		DNPH Silica Gel (SKC 226-119)
	Excess								1000	10	Excess
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess
					ļ						

PRE-PRODUCTION FI - SERIES SAMPLE PLAN

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/14/2003											
RUN 2											
THC	FI002	Х									TOTAL
M-18	FI00201		1						60	1	Carbopak charcoal
M-18	FI00202			1					60	2	Carbopak charcoal
	Excess								60	3	Excess
Gas, CO, CO2	FI00203		1						60	4	Tedlar Bag
	Excess								500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FI00204		1						1000	7	100/50 mg Charcoal (SKC 226-01)
NIOSH 1500				1					1000	8	100/50 mg Charcoal (SKC 226-01)
TO11	FI00206		1						1000	9	DNPH Silica Gel (SKC 226-119)
TO11	FI00207			1					1000	10	DNPH Silica Gel (SKC 226-119)
	Excess								1000		Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

		-	-			-		_			
Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/15/2003											
RUN 3											
THC	FI003	Х									TOTAL
M-18	FI00301		1						60	1	Carbopak charcoal
M-18	FI00302					1			60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FI00303		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FI00304		1						1000	7	100/50 mg Charcoal (SKC 226-01)
	Excess								1000	8	Excess
TO11	FI00305		1						1000		DNPH Silica Gel (SKC 226-119)
	Excess								1000	10	Excess
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/15/2003									_		
RUN 4											
THC	FI004	Х		-							TOTAL
M-18	FI00401		1						60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FI00402		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FI00403		1						1000	7	100/50 mg Charcoal (SKC 226-01)
	Excess								1000	8	Excess
TO11	FI00404		1						1000	9	DNPH Silica Gel (SKC 226-119)
	Excess								1000	10	Excess
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

	#			ite		Irough		Duplicate	(uim/l	Channel	
Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike D	Flow (ml/min)	Train C	Comments
7/15/2003											
RUN 5											
THC	FI005	Х									TOTAL
M-18	FI00501		1						60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FI00502		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FI00503		1						1000	7	100/50 mg Charcoal (SKC 226-01)
	Excess								1000	8	Excess
TO11	FI00504		1						1000	9	DNPH Silica Gel (SKC 226-119)
	Excess								1000	10	Excess
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/16/2003											
RUN 6				_							
THC	FI006	Х									TOTAL
M-18	FI00601		1						60	1	Carbopak charcoal
	Excess			-					60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FI00602		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FI00603		1						1000	7	100/50 mg Charcoal (SKC 226-01)
	Excess								1000	8	Excess
TO11	FI00604		1						1000	9	DNPH Silica Gel (SKC 226-119)
	Excess								1000	10	Excess
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

TRETROBOOTION								-			
Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/16/2003											
RUN 7											
THC	FI007	Х									TOTAL
M-18	FI00701		1						60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FI00702		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FI00703		1						1000	7	100/50 mg Charcoal (SKC 226-01)
	Excess								1000	8	Excess
TO11	FI00704		1						1000	9	DNPH Silica Gel (SKC 226-119)
	Excess								1000		Excess
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/16/2003											
RUN 8											
THC	FI008	Х									TOTAL
M-18	FI00801		1						60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FI00802		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FI00803		1						1000	7	100/50 mg Charcoal (SKC 226-01)
	Excess								1000	8	Excess
TO11	FI00804		1						1000	9	DNPH Silica Gel (SKC 226-119)
	Excess								1000		Excess
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

											-
Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/17/2003											
RUN 9											
THC	FI009	Х									TOTAL
M-18	FI00901		1						60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FI00902		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FI00903		1						1000	7	100/50 mg Charcoal (SKC 226-01)
	Excess								1000	8	Excess
TO11	FI00904		1						1000	9	DNPH Silica Gel (SKC 226-119)
	Excess								1000	10	Excess
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

TECHNIKON TEST PLAN

- > CONTRACT NUMBER: 1410 TASK NUMBER: 1.1.1 Series: FJ
- > SAMPLE EVENTS : Estimated 9
- > SITE: X PRE-PRODUCTION ____ FOUNDRY
- > TEST TYPE: Product Test on H & G SLIKEASE[®] vegetable oil based Liquid Parting
- > METAL TYPE: <u>Class 30 gray iron</u>
- > MOLD TYPE: 4-on coreless star greensand and Vegetable oil liquid parting with no seacoal
- > NUMBER OF MOLDS: <u>9 + pattern spray conditioning</u>.
- > CORE TYPE: <u>None</u>
- > **TEST DATE:** START: 21 July 2003

FINISHED: 31 July 2003

TEST OBJECTIVES:

Measure Pouring, Cooling, and Shakeout emissions from liquid parting with coal-less greensand mix. Compare to Liquid parting baseline FI. Results shall be reported as pounds of emission/pound of liquid parting and pounds of emission /ton of metal poured.

VARIABLES:

The pattern will be the 4-on star. The mold will be made with Wexford W450 sand, 7% western and southern bentonite in a 5:2 ratio, no seacoal, tempered to 40-45% compactability, mechanically compacted. A vegetable based liquid parting H&G SLIKEASE[®] will be used. The molds will be maintained at 80-90°F prior to pouring. The sand heap will be maintained at 900 pounds. Molds will be poured with iron at 2680 +/- 10°F. Mold cooling will be 45minutes follow by 15 minutes of shakeout, or until no more material remains to be shaken out. The initial process air temperature will be maintained at 85-90°F. Emission testing will be 75 minutes.

BRIEF OVERVIEW:

The 4 on star pattern is a new test pattern that will be used for greensand baselines and product comparisons. The new Osborn Jolt squeeze machine will be an improvement over previously hand rammed molds, which are inherently inconsistent. This test is to measure the product emissions compared to the baseline emissions for this pattern and the Osborn machine combination with liquid parting and no seacoal.

SPECIAL CONDITIONS:

The process will include rigorous maintenance of the size of sand heap and maintenance of the material and testing environmental temperatures to reduce seasonal and daily temperature dependent influence on the emissions

Process Engineering Manager (Technikon)	Date	
V.P. Measurement Technology (Technikon)	Date	
V.P. Operations (Technikon)	Date	
Test Design Committee Representative	Date	
Emission Committee Representative	Date	

Series FJ

PCS Pattern Spray Product test with No-coal Greensand & Mechanized Molding Process Instructions

A. Experiment:

- 1. Measure emissions from a no coal greensand mold with pattern spray applied.
- 2. Compare to baseline FI. The molds shall be started with all virgin Wexford W450 sand, bonded with 7% Western & Southern Bentonite in the ratio of 5:2.
- **3.** The molds shall be tempered with potable water to 40-45% compactability, poured at constant weight, temperature, surface area, & shape factor. This test will recycle the same mold material, replacing burned clay with new materials after each casting cycle.

B. Materials:

- 1. Mold sand: Virgin mix of Wexford W450 lake sand, western and southern bentonites in ratio of 5:2, and potable water per recipe. No seacoal.
- 2. Core: None
- **3.** Metal: Class 30-35 gray cast iron poured at 2680°F.
- **4.** Pattern Spray: H&G SLIKEASE[®] vegetable based liquid parting.

Caution: Observe all safety precautions attendant to these operations as delineated in the Preproduction operating and safety instruction manual.

- **5.** The following test shall be conducted:
 - **a.** Sand batch: Single sand batch to be used for all FJ molds.
 - **b.** The recycled sand heap shall be maintained at 900+-10 pounds
 - c. FJ001: Virgin mix as described above, un-vented mold.
 - d. FJ002-FJ0XX: Re-mulled, reconstituted greensand, potable water, un-vented molds.
 - e. 20 grams of H&G SLIKEASE ® parting spray shall be brushed on each mold half.
 - **f.** Emission absorption tube sampling will begin after THC determination of stability of parting spray content.
- **C.** Sand preparation
 - **1.** Start up batch: make 1, FJ001.
 - **a.** Thoroughly clean the pre-production muller elevator and molding hoppers.
 - **b.** Weigh and add 1225 +/- 10 pounds of new Wexford W450 Lakesand, per the recipe, to the running pre-production muller.

- **c.** Add 5 pounds of potable to the muller to suppress dust distributing it across the sand. Allow to mix for 1 minute.
- **d.** Add the clays slowly to the muller to allow them to be distributed throughout the sand mass in proportion to the sand weight per the recipe for this test.
- e. Dry mull for about 3 minutes to allow distribution and some grinding of the clays to occur.
- **f.** Temper the sand-clay mixture slowly, with potable water, to allow for distribution.
- **g.** After about 2 gallons of water have been added allow 30 seconds of mixing then start taking compactability test samples.
- **h.** Based on each test add water incrementally to adjust the temper. Allow 1 minute of mixing. Retest. Repeat until the compactability is in the range 40-45%.
- i. Discharge the sand into the mold station elevator.
- **j.** Grab sufficient sample after the final compactability test to fill a quart zip-lock bag. Label bag with the test series and sequence number, date, and time of day and deliver it immediately to the sand lab for analysis
- **k.** Record the total sand mixed in the batch, the total of each type of clay added to the batch, the amount of water added, the total mix time, the final compactability and sand temperature at charge and discharge.
- I. The sand will be immediately characterized for Methylene Blue Clay, Moisture content, Compactability, Green Compression strength, 1800°F loss on ignition (LOI), and 900°F volatiles. Each volatile and LOI test requires a separate 50 gram sample from the collected sand.
- **m.** Empty the extra greensand from the mold hopper into a clean empty dump hopper whose tare weight is known. Set this sand aside to be used to maintain the recycled batch at 900+/-10 pounds
- 2. Re-mulling: FJ002
 - **a.** Add to the sand recovered from poured mold FI001sufficient pre-blended sand so that the sand batch weight is 900 +/- 10 pounds. Record the sand weight.
 - **b.** Return the sand to the muller and dry blend for about one minute.
 - **c.** Add the clays, as directed by the process engineering staff, slowly to the muller to allow them to be distributed throughout the sand mass.
 - **d.** Add 5 pounds of water to the muller to suppress dust distributing it across the sand. Allow to mix for 1 minute.
 - e. Follow the above procedure beginning at B.1.f.
- **3.** Re-mulling: FJ003-FJ0XX
 - **a.** Add to the sand recovered from the previous poured mold, mold machine spill sand, the residual mold hopper sand and sufficient pre-blended sand to total 900 +/- 10 pounds.
 - **b.** Return the sand to the muller and dry blend for about one minute.
 - **c.** Add the clays, as directed by the process engineering staff, slowly to the muller to allow them to be distributed throughout the sand mass.

- **d.** Add 5 pounds of water to the muller to suppress dust distributing it across the sand. Allow to mix for 1 minute.
- **e.** Follow the above procedure beginning at B.1.f.
- **D.** Molding: 4- on star pattern.
 - **1.** Pattern preparation:
 - **a.** Inspect and tighten all loose pattern and gating pieces.
 - **b.** Repair any damaged pattern or gating parts.
 - 2. Mount the drag 4-on star pattern with gating into the mold machine bolster and bolt it down tightly.
 - **a.** Weigh a 500 ml beaker, 200 ml of H&G SLIKEASE[®] parting spray and a 1-inch brush immersed in the parting spray.
 - **b.** Incrementally brush parting spray evenly over each side of the entire pattern until the gross weight of the beaker, residual parting spray, and the immersed brush are twenty (20) grams lighter that in C.2.a.
 - **c.** Repeat for the other side of the pattern in turn.
 - **d.** Repeat C.2.b-c for each mold cycle.
 - **3.** Mount a cope follower board containing a pour cup pattern to the underside of the squeeze head plate.
 - 4. Check the alignment of the pour cup by manually raising the table using the squeeze bypass valve at the bottom rear of the machine until the sprue pierces the pour cup pattern. Move the pour cup pattern as necessary.
 - 5. Remove the sprue if making a mold drag half. Leave it attached if making a cope half.
 - 6. Use the overhead crane to place the pre-weighed drag/cope flask on the mold machine table, parting line surface down.
 - 7. Locate a 24 x 24 x4 inch deep wood upset on top of the flask.
 - 8. Make the green sand mold on the Osborn Whisper Ram Jolt-Squeeze mold machine

WARNING: Only properly trained personnel may operate this machine. Proper personal protective equipment must be worn at all times while operating this equipment, including safety glasses with side shields and a properly fitting hard hat. Industrial type boots are highly recommended.

WARNING: Stand clear of the mold machine table and swinging head during the following operation or serious injury or death could result.

9. Open the air supply to the mold machine.

WARNING: The squeeze head may suddenly swing to the outboard side or forward. Do not stand in the outer corners of the molding enclosure.

10. On the operator's panel turn the POWER switch to ON.

- **11.** Turn the RAM-JOLT-SQUEEZE switch to ON.
- **12.** Turn the DRAW UP switch to AUTO
- **13.** Set the PRE-JOLT timer to 4-5 seconds.
- **14.** Set the squeeze timer to 8 seconds.
- **15.** Manually riddle a half to one inch or so of sand on the pattern using a ¹/₄ inch mesh riddle. Source the sand from the overhead mold sand hopper by actuating the CHATTER GATE valve located under the operators panel.
- **16.** Fill the 24 x 24 x 10 inch flask and the upset with greensand from the overhead molding hopper.
- **17.** Manually level sand in the upset. By experience manually adjust the sand depth so that the resulting compacted mold is fractionally above the flask only height.

WARNING: Failure to stand clear of the molding table and flasks in the following operations could result in serious injury as this equipment is about to move up and down with great force.

18. Initiate the settling of the sand in the flask by pressing the PRE-JOLT push button. Allow this cycle to stop before proceeding.

WARNING: Stand clear of the entire mold machine during the following operations. Several of the machine parts will be moving. Failure to stand clear could result in severe injury even death.

19. Using both hands initiate the automatic machine sequence by simultaneously pressing and releasing the green push buttons on either side of the operators panel. The machine will squeeze and jolt the sand in the flask and then move the squeeze head to the side.

WARNING: Do no re-approach the machine until the squeeze head has stopped at the side of the machine.

- **20.** Remove the upset and set it aside.
- **21.** Screed the bottom of the mold flat if required.
- **22.** Press and release the LOWER DRAW/STOP push button to separate the flask and mold from the pattern.
- **23.** Use the overhead crane to lift the mold half and remove it from the machine.
- **24.** Finally, press and release the draw down pushbutton to cause the draw frame to return to the start position.
- **25.** If the mold half is a drag, roll it parting line side up, set it on the floor, blow it out, and cover it to keep it clean.
- **26.** Close the cope over the drag being careful not to crush anything.
- **27.** Clamp the flask halves together.
- **28.** Weigh and record the weight of the closed un-poured mold, the pre-weighed flask, and the sand weight by difference
- **29.** Deliver the mold to the previously cleaned shakeout to be poured.
- **30.** Cover the mold with the emission hood.
- **E.** Shakeout.

- 1. After the cooling time prescribed in the test plan turn on the shakeout unit and run it for until the greensand has passed into the hopper below.
- 2. Turn off the shakeout, remove the flask with casting, and recover the sand from the hopper and surrounding floor.
- **3.** Weigh and record the metal poured and the total sand weight recovered and rejoined with the left over mold sand from the molding hopper.

F. Melting:

- **1.** Initial charge:
 - **a.** Charge the furnace according to the heat recipe.
 - **b.** Place part of the steel scrap on the bottom, followed by carbon alloys, and the balance of the steel.
 - **c.** Place a pig on top on top.
 - **d.** Bring the furnace contents to the point of beginning to melt over a period of 1 hour at reduced power.
 - e. Add the balance of the metallics under full power until all is melted and the temperature has reached 2600 to 2700° F.
 - **f.** Slag the furnace and add the balance of the alloys.
 - **g.** Raise the temperature of the melt to 2700°F and take a DataCast 2000 sample. The temperature of the primary liquidus (TPL) must be in the range of 2200-2350°F.
 - **h.** Hold the furnace at 2500-2550°F until near ready to tap.
 - i. When ready to tap raise the temperature to 2700° F and slag the furnace.
 - **j.** Record all metallic and alloy additions to the furnace, tap temperature, and pour temperature. Record all furnace activities with an associated time.
- 2. Back charging.
 - **a.** Back charge the furnace according to the heat recipe,
 - **b.** Charge a few pieces of steel first to make a splash barrier, followed by the carbon alloys.
 - **c.** Follow the above steps beginning with E.1.e.
- **3.** Emptying the furnace.
 - **a.** Pig the extra metal only after the last emission measurement is complete to avoid contaminating the air sample.
 - **b.** Cover the empty furnace with ceramic blanket to cool.

G. Pouring:

- **1.** Preheat the ladle.
 - **a.** Tap 400 pounds more or less of 2700°F metal into the cold ladle.
 - **b.** Casually pour the metal back to the furnace.
 - **c.** Cover the ladle.

- **d.** Reheat the metal to $2780 \pm 20^{\circ}$ F.
- e. Tap 450 pounds of iron into the ladle while pouring inoculating alloys onto the metal stream near its base.
- **f.** Cover the ladle to conserve heat.
- g. Move the ladle to the pour position, and wait until the metal temperature reaches $2680 + 10^{\circ}$ F.
- **h.** Commence pouring keeping the sprue full.
- i. Upon completion return the extra metal to the furnace, and cover the ladle.

Steven Knight Mgr. Process Engineering

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/28/2003											FJ CONDITIONING - RUN 1
FJ CR-1											
ТНС		х									

PRE-PRODUCTION FJ - SERIES SAMPLE PLAN

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/28/2003											FJ CONDITIONING - RUN 2
FJ CR-2											
THC		х									

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/29/2003											
RUN 1											
THC	FJ001	Х									TOTAL
M-18	FJ00101		1						60	1	Carbopak charcoal
M-18	FJ00102				1				0		Carbopak charcoal
M-18 MS	FJ00103		1						60	2	Carbopak charcoal
M-18 MS	FJ00104			1					60	3	Carbopak charcoal
Gas, CO, CO2	FJ00105		1						60	4	Tedlar Bag
Gas, CO, CO2	FJ00106				1				0		Tedlar Bag
	Excess								500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FJ00107		1						1000	7	100/50 mg Charcoal (SKC 226-01)
NIOSH 1500	FJ00108				1				0		100/50 mg Charcoal (SKC 226-01)
	Excess								1000	8	Excess
TO11	FJ00109		1						1000	9	DNPH Silica Gel (SKC 226-119)
TO11	FJ00110				1				0		DNPH Silica Gel (SKC 226-119)
	Excess								1000	10	Excess
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess							-	5000	13	Excess

TRETRODUCTION								•			
Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/29/2003											
RUN 2											
THC	FJ002	Х									TOTAL
M-18	FJ00201		1						60	1	Carbopak charcoal
M-18	FJ00202			1					60	2	Carbopak charcoal
	Excess								60	3	Excess
Gas, CO, CO2	FJ00203		1						60	4	Tedlar Bag
	Excess								500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FJ00204		1						1000	7	100/50 mg Charcoal (SKC 226-01)
NIOSH 1500	FJ00205			1					1000	8	100/50 mg Charcoal (SKC 226-01)
TO11	FJ00206		1						1000	9	DNPH Silica Gel (SKC 226-119)
TO11	FJ00207			1					1000	10	DNPH Silica Gel (SKC 226-119)
	Excess								1000	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

Method 7/29/2003	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
RUN 3											
THC	FJ003	Х									TOTAL
M-18	FJ00301		1						60	1	Carbopak charcoal
M-18	FJ00302					1			60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								40	3	Excess
Gas, CO, CO2	FJ00303		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FJ00304		1						500	7	100/50 mg Charcoal (SKC 226-01)
	Excess								500	8	Excess
TO11	FJ00305		1						500	9	DNPH Silica Gel (SKC 226-119)
	Excess								500	10	Excess
	Excess								500	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

	Sample #	ta	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	
Method	Saı	Data	Sal	Dυ	Bla	Bre	Spi	Sp	Б	Tra	Comments
7/30/2003											
RUN 4											
THC	FJ004	Х									TOTAL
M-18	FJ00401		1						60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FJ00402		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FJ00403		1	-					500	7	100/50 mg Charcoal (SKC 226-01)
TOUL	Excess			-					500	8	Excess
TO11	FJ00404		1						500	9	DNPH Silica Gel (SKC 226-119)
	Excess								500	10	Excess
	Excess								500	11 12	Excess TOTAL
	Moieturo		4								
	Moisture		1	-					500		
	Moisture Excess		1						5000	12	Excess
	Excess	EQ		м							
PRE-PRODUCTION	Excess	ES		MF	PLE	PI	_AI	N			
Method	Excess	Data		Duplicate	Blank	Breakthrough	Spike	Spike Duplicate			
Method 7/30/2003	Excess FJ - SERI		SA						5000	13	Excess
Method 7/30/2003 RUN 5	Excess FJ - SERI au Sam be s	Data	SA						5000	13	Excess Comments
Method 7/30/2003 RUN 5 THC	Excess FJ - SERI # ad web S FJ005		Sample						Flow (ml/min)	Train Channel	Excess Comments TOTAL
Method 7/30/2003 RUN 5	Excess FJ - SERI # • • • • • • • • • • • • • • • • • •	Data	SA						Elow (ml/min)	Train Channel	Excess Comments TOTAL Carbopak charcoal
Method 7/30/2003 RUN 5 THC	FJ005 FJ00501 Excess	Data	Sample						000 60 60	Train Channel	Excess Comments TOTAL Carbopak charcoal Excess
Method 7/30/2003 RUN 5 THC M-18	FJO05 FJ00501 Excess Excess	Data	Sample 1						5000 Elow (ml/min)	13 Train Channel	Excess Comments TOTAL Carbopak charcoal Excess Excess
Method 7/30/2003 RUN 5 THC	FJO05 FJ00501 Excess FJ00502	Data	Sample						5000 Elow (ml/min)	13 Train Channel 1 2 3 4	Excess Comments TOTAL Carbopak charcoal Excess Excess Tedlar Bag
Method 7/30/2003 RUN 5 THC M-18	FJ005 FJ00501 Excess FJ00502 Excess	Data	Sample 1						5000 Elow (ml/min) 60 60 60 60 60 60 60 60 60 60	13 Lain Channel 1 2 3 4 5	Excess Comments TOTAL Carbopak charcoal Excess Excess Tedlar Bag Excess
Method 7/30/2003 RUN 5 THC M-18 Gas, CO, CO2	FJO05 FJ00501 Excess FJ00502 Excess Excess Excess	Data	Sample						5000 Low (ml/min) 60 60 60 60 60 60 500 500	13 Lain Channel 2 5 6	Excess Comments TOTAL Carbopak charcoal Excess Excess Tedlar Bag Excess Excess Excess Excess
Method 7/30/2003 RUN 5 THC M-18	FJ005 FJ00501 Excess FJ00502 Excess FJ00503	Data	Sample						5000 Line (uimin) 60 60 60 60 60 500 500 500 500	13 Lain Channel 1 2 3 4 5 6 7 7	Excess Comments TOTAL Carbopak charcoal Excess Excess Tedlar Bag Excess Tedlar Bag Excess Excess Tedlar Bag Excess Excess 100/50 mg Charcoal (SKC 226-01)
Method 7/30/2003 RUN 5 THC M-18 Gas, CO, CO2 NIOSH 1500	FJO05 FJ00501 Excess FJ00502 Excess FJ00503 Excess FJ00503 Excess	Data	Sample						5000 Low (ml/min) 60 60 60 60 60 500 500 500 500	13 Lain Channel 2 3 4 5 6 7 8 8	Excess Comments TOTAL Carbopak charcoal Excess Excess Tedlar Bag Excess Tedlar Bag Excess Excess 100/50 mg Charcoal (SKC 226-01) Excess
Method 7/30/2003 RUN 5 THC M-18 Gas, CO, CO2	Excess FJ - SERI FJ - SERI FJ005 FJ00501 Excess FJ00502 Excess FJ00502 Excess FJ00503 Excess FJ00503 Excess FJ00504	Data	Sample						5000 Line (uimin) Elow 60 60 60 60 60 500 500 500 500	13 Lain Channel 2 2 2 2 2 2 2 2 2 2 2 2 2	Excess Comments TOTAL Carbopak charcoal Excess Excess Tedlar Bag Excess Tedlar Bag Excess Excess 100/50 mg Charcoal (SKC 226-01) Excess DNPH Silica Gel (SKC 226-119)
Method 7/30/2003 RUN 5 THC M-18 Gas, CO, CO2 NIOSH 1500	Excess FJ - SERI FJ - SERI FJ - SERI FJ - SERI Excess FJ00501 Excess FJ00502 Excess FJ00502 Excess FJ00503 Excess FJ00503 Excess FJ00504 Excess	Data	Sample						5000 (uiuu) Moluui 60 60 60 60 60 500 500 500 500	13 Lagin Channel Lagin Channel 6 7 9 01 01	Excess Comments TOTAL Carbopak charcoal Excess Excess Tedlar Bag Excess Tedlar Bag Excess 100/50 mg Charcoal (SKC 226-01) Excess DNPH Silica Gel (SKC 226-119) Excess
Method 7/30/2003 RUN 5 THC M-18 Gas, CO, CO2 NIOSH 1500	Excess FJ - SERI FJ - SERI FJ005 FJ00501 Excess FJ00502 Excess FJ00502 Excess FJ00503 Excess FJ00503 Excess FJ00504	Data	Sample						5000 Line (uimin) Elow 60 60 60 60 60 500 500 500 500	13 Lain Channel 2 2 2 2 2 2 2 2 2 2 2 2 2	Excess Comments TOTAL Carbopak charcoal Excess Excess Tedlar Bag Excess Tedlar Bag Excess Excess 100/50 mg Charcoal (SKC 226-01) Excess DNPH Silica Gel (SKC 226-119)

Method 7/30/2003	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
RUN 6											
THC	FJ006	Х									TOTAL
M-18	FJ00601		1						60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FJ00602		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500	6	Excess
NIOSH 1500	FJ00603		1						500	7	100/50 mg Charcoal (SKC 226-01)
	Excess								500	8	Excess
TO11	FJ00604		1						500	9	DNPH Silica Gel (SKC 226-119)
	Excess								500	10	Excess
	Excess								500	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

Method 7/31/2003	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments	
RUN 7												
THC	FJ007	Х									TOTAL	
M-18	FJ00701		1						60	1	Carbopak charcoal	
	Excess								60	2	Excess	
	Excess								60	3	Excess	
Gas, CO, CO2	FJ00702		1						60	4	Tedlar Bag	
	Excess		1						500	5	Excess	
	Excess								500	6	Excess	
NIOSH 1500	FJ00703		1						500	7	100/50 mg Charcoal (SKC 226-01)	
	Excess								500	8	Excess	
TO11	FJ00704		1						500		DNPH Silica Gel (SKC 226-119)	
	Excess								500	10	Excess	
	Excess								500	11	Excess	
	Moisture		1						500	12	TOTAL	
	Excess								5000	13	Excess	

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments		
7/31/2003													
RUN 8	E 1008	Х									тота		
	FJ008 FJ00801	X	1						60	1	TOTAL		
101-10	Excess		1						60		Carbopak charcoal Excess		
	Excess								60		Excess		
Gas, CO, CO2	FJ00802		1						60	4	Tedlar Bag		
,,	Excess		1						500	5	Excess		
	Excess								500	6	Excess		
NIOSH 1500	FJ00803		1						500	7	100/50 mg Charcoal (SKC 226-01)		
	Excess								500	8	Excess		
TO11	FJ00804		1						500	9	DNPH Silica Gel (SKC 226-119)		
	Excess								500	10	Excess		
	Excess								500	11	Excess		
	Moisture		1						500	12	TOTAL		
	Excess								5000	13	Excess		

Method	Sample #	Data	Sample	Duplicate	Blank	Breakthrough	Spike	Spike Duplicate	Flow (ml/min)	Train Channel	Comments
7/31/2003											
RUN 9											
THC	FJ009	Х									TOTAL
M-18	FJ00901		1						60	1	Carbopak charcoal
	Excess								60	2	Excess
	Excess								60	3	Excess
Gas, CO, CO2	FJ00902		1						60	4	Tedlar Bag
	Excess		1						500	5	Excess
	Excess								500		Excess
NIOSH 1500	FJ00903		1						500	7	100/50 mg Charcoal (SKC 226-01)
	Excess								500	8	Excess
TO11	FJ00904		1						500	9	DNPH Silica Gel (SKC 226-119)
	Excess								500	10	Excess
	Excess								500	11	Excess
	Moisture		1						500	12	TOTAL
	Excess								5000	13	Excess

this page intentionally left blank

APPENDIX B TEST SERIES FI AND FJ DETAILED EMISSION RESULTS

this page intentionally left blank

Test Plan FI Individual Test Results – Lb/Tn Metal

S												
HAPs	COMPOUND / SAMPLE NUMBER	FI001	FI002	FI003	F1004	F1005	F1006	F1007	F1008	F1009	Avenage	STDEV
	Test Dates	7/14/03	7/14/03	7/15/03	7/15/03	7/15/03	7/16/03	7/16/03	7/16/03	7/17/03	Average	SIDEV
	TGOC as Propane	7.96E-01	9.11E-01	9.08E-01	8.37E-01	//13/03 I	8.60E-01	9.29E-01	8.63E-01	8.18E-01	8.65E-01	4.76E-02
	HC as Hexane	1.53E-01	1.80E-01	1.84E-01	1.67E-01	1.67E-01	1.55E-01	1.64E-01	1.67E-01	1.74E-01	1.68E-01	1.02E-02
	Sum of VOCs	8.40E-02	9.46E-02	8.69E-02	8.74E-01	7.27E-02	7.74E-02	7.99E-02	I.07L-01	7.19E-02	8.19E-02	7.85E-03
	Sum of HAPs	6.78E-02	7.56E-02	6.87E-02	6.92E-02	5.61E-02	6.02E-02	6.12E-02	I	5.59E-02	6.43E-02	7.04E-03
	Sum of POMs	2.57E-03	3.38E-03	3.25E-03	3.36E-03	3.41E-03	2.81E-03	2.99E-03	I	2.49E-03	3.03E-03	3.74E-04
		2.5712 05	5.50 <u>H</u> 05	<u> </u>		Organic HA		2.771 05	1	2.4712 03	5.051 05	<u>3.74L 04</u>
x	Benzene	3.18E-02	3.58E-02	3.31E-02	3.31E-02	2.49E-02	2.81E-02	2.91E-02	I	2.73E-02	3.04E-02	3.64E-03
x	Toluene	1.13E-02	1.22E-02	1.14E-02	1.09E-02	9.59E-03	1.04E-02	9.99E-03	I	9.20E-03	1.06E-02	1.00E-03
x	m.p-Xvlene	7.89E-03	8.08E-03	6.87E-03	7.83E-03	6.93E-03	6.47E-03	6.38E-03	I	5.51E-03	7.00E-03	8.92E-04
x	Acetaldehyde	3.02E-03	3.49E-03	3.08E-03	2.85E-03	3.08E-03	2.86E-03	2.61E-03	3.18E-03	3.19E-03	3.04E-03	2.51E-04
х	o-Xylene	2.57E-03	2.87E-03	2.63E-03	2.60E-03	2.29E-03	2.44E-03	2.47E-03	Ι	2.30E-03	2.52E-03	1.90E-04
x	Naphthalene	1.91E-03	2.56E-03	2.44E-03	2.55E-03	2.57E-03	2.10E-03	2.24E-03	Ι	1.87E-03	2.28E-03	2.92E-04
x	Hexane	2.72E-03	2.57E-03	2.50E-03	2.52E-03	Ι	2.31E-03	2.36E-03	Ι	8.20E-04	2.26E-03	6.48E-04
x	Formaldehyde	1.84E-03	2.38E-03	1.82E-03	1.70E-03	2.06E-03	1.51E-03	1.40E-03	1.70E-03	1.77E-03	1.80E-03	2.89E-04
x	Ethylbenzene	1.65E-03	1.75E-03	1.54E-03	1.69E-03	1.47E-03	1.40E-03	1.45E-03	Ι	1.30E-03	1.53E-03	1.57E-04
x	Styrene	9.22E-04	1.21E-03	1.01E-03	1.07E-03	9.22E-04	9.45E-04	9.47E-04	Ι	9.52E-04	9.98E-04	1.00E-04
x	Propionaldehyde	6.19E-04	7.50E-04	5.84E-04	6.17E-04	6.26E-04	6.14E-04	5.71E-04	7.19E-04	7.08E-04	6.45E-04	6.36E-05
x	Phenol	6.43E-04	7.33E-04	6.02E-04	6.20E-04	5.86E-04	ND	6.44E-04	Ι	0.00E+00	4.79E-04	2.99E-04
x	2 2-Methylnaphthalene	3.66E-04	4.64E-04	4.59E-04	4.56E-04	4.65E-04	3.91E-04	4.12E-04	Ι	3.51E-04	4.20E-04	4.68E-05
x	1-Methylnaphthalene	2.91E-04	3.54E-04	3.57E-04	3.53E-04	3.81E-04	3.13E-04	3.36E-04	Ι	2.74E-04	3.32E-04	3.66E-05
x	2-Butanone	2.80E-04	3.37E-04	3.24E-04	2.89E-04	2.85E-04	2.67E-04	2.70E-04	3.07E-04	3.18E-04	2.98E-04	2.51E-05
	1,2-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
	1,3-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
	1,5-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
	1,6-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	I	ND	ND	NA
	1,8-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
	2,3,5-Trimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
	2,3-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	I	ND	ND	NA
	2,6-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	I	ND	ND	NA
	2,7-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	I	ND	ND	NA
	Acenaphthalene	ND	ND	ND	ND	ND	ND	ND	I	ND	ND	NA
X	Biphenyl	ND	ND	ND	ND	ND	ND	ND	1	ND	ND	NA
x	m,p-Cresol	ND	ND	ND	ND	ND	ND	ND	I	ND	ND	NA
X	o-Cresol	ND	ND	ND	ND	ND	ND	ND			ND	NA
X	Acrolein	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA

HAPs POMs	COMPOUND / SAMPLE											
PO	NUMBER	FI001	FI002	FI003	FI004	FI005	FI006	FI007	FI008	FI009	Average	STDEV
	Test Dates	7/14/03	7/14/03	7/15/03	7/15/03	7/15/03	7/16/03	7/16/03	7/16/03	7/17/03		
					Oth	er VOCs						
	Heptane	3.97E-03	4.10E-03	4.39E-03	4.62E-03	4.00E-03	4.41E-03	4.99E-03	Ι	4.48E-03	4.37E-03	3.44E-04
	Tetradecane	2.28E-03	2.85E-03	3.06E-03	3.09E-03	3.29E-03	2.59E-03	3.13E-03	Ι	2.64E-03	2.87E-03	3.39E-04
	1,2,4-Trimethylbenzene	2.51E-03	3.29E-03	3.05E-03	2.99E-03	2.59E-03	2.98E-03	2.84E-03	Ι	2.65E-03	2.86E-03	2.64E-04
	Octane	2.11E-03	2.21E-03	2.18E-03	2.28E-03	2.04E-03	2.16E-03	2.31E-03	Ι	2.11E-03	2.18E-03	9.25E-05
	3-Ethyltoluene	1.51E-03	1.71E-03	1.41E-03	1.45E-03	1.37E-03	1.29E-03	1.50E-03	Ι	1.17E-03	1.43E-03	1.62E-04
	1,3,5-Trimethylbenzene	7.95E-04	9.69E-04	8.78E-04	8.49E-04	7.73E-04	8.35E-04	8.76E-04	Ι	7.14E-04	8.36E-04	7.73E-05
	1,2,3-Trimethylbenzene	6.36E-04	8.45E-04	7.08E-04	7.18E-04	6.86E-04	6.92E-04	7.09E-04	I	6.17E-04	7.01E-04	6.83E-05
	Indene	7.32E-04	9.34E-04	7.96E-04	7.57E-04	7.42E-04	7.05E-04	6.77E-04	I	0.00E+00	6.68E-04	2.81E-04
	Benzaldehyde	3.66E-04	4.26E-04	3.28E-04	3.64E-04	3.69E-04	3.36E-04	3.66E-04	3.61E-04	4.13E-04	3.70E-04	3.16E-05
	Butyraldehyde/Methacrolein	3.43E-04	4.26E-04	3.43E-04	3.52E-04	3.54E-04	3.34E-04	3.19E-04	3.80E-04	3.98E-04	3.61E-04	3.39E-05
	2-Ethyltoluene	3.54E-04	4.29E-04	3.76E-04	3.74E-04	ND	3.58E-04	3.87E-04	Ι	3.37E-04	3.27E-04	1.35E-04
	Pentanal	1.90E-04	2.37E-04	1.87E-04	1.91E-04	1.86E-04	1.69E-04	1.68E-04	2.01E-04	1.92E-04	1.91E-04	2.04E-05
	Hexaldehyde	1.68E-04	2.09E-04	1.35E-04	1.63E-04	1.53E-04	1.40E-04	1.61E-04	1.67E-04	1.59E-04	1.62E-04	2.11E-05
	Undecane	2.59E-04	1.36E-04	ND	ND	ND	2.34E-04	2.36E-04	Ι	1.95E-04	1.32E-04	1.16E-04
	o,m,p-Tolualdehyde	ND	3.17E-04	3.62E-04	ND	ND	ND	ND	ND	ND	7.55E-05	1.50E-04
	1,3-Diethylbenzene	ND	I	ND	ND	NA						
	2,4-Dimethylphenol	ND	I	ND	ND	NA						
	2,6-Dimethylphenol	ND	I	ND	ND	NA						
	Cyclohexane	ND	Ι	ND	ND	NA						
	Decane	ND	Ι	ND	ND	NA						
	Dodecane	ND	Ι	ND	ND	NA						
	Indan	ND	Ι	ND	ND	NA						
	Nonane	ND	Ι	ND	ND	NA						
	n-Propylbenzene	ND	Ι	ND	ND	NA						
	Crotonaldehyde	ND	NA									

HAPs	POMs	COMPOUND / SAMPLE NUMBER	FI001	F1002	F1003	F1004	F1005	F1006	F1007	F1008	F1009	Average	STDEV
		Test Dates	7/14/03	7/14/03	7/15/03	7/15/03	7/15/03	7/16/03	7/16/03	7/16/03	7/17/03		
						Othe	r Analytes						
		Acetone	1.79E-03	1.94E-03	1.79E-03	1.78E-03	1.69E-03	1.61E-03	1.72E-03	1.72E-03	1.84E-03	1.76E-03	9.56E-05
		Carbon Dioxide	1.92E+01	1.83E+01	1.99E+01	1.89E+01	1.73E+01	1.91E+01	1.95E+01	1.89E+01	1.75E+01	1.87E+01	8.60E-01
		Methane	1.74E-02	3.16E-02	3.16E-02	3.07E-02	3.40E-02	3.02E-02	3.36E-02	3.16E-02	3.45E-02	3.06E-02	5.15E-03
		Carbon Monoxide	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
		Ethane	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
		Propane	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
		Isobutane	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
		Butane	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
		Neopentane	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
		Isopentane	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
		Pentane	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA

Test Plan FI Individual Test Results – Lb/Tn Metal

I: Data rejected based on data validation considerations.

ND: Non Detect; NA: Not Applicable

All "Other Analytes" are not included in the Sum of VOCs or HAPs.

HAPs	POMs	COMPOUND / SAMPLE NUMBER	FI001	FI002	FI003	FI004	F1005	FI006	FI007	F1008	F1009	Average	STDEV
	_	Test Dates	7/14/03	7/14/03	7/15/03	7/15/03	7/15/03	7/16/03	7/16/03	7/16/03	7/17/03		
		TGOC as Propane	4.53E-01	4.84E-01	4.89E-01	4.44E-01	Ι	4.85E-01	5.04E-01	4.61E-01	4.54E-01	4.72E-01	2.11E-02
		HC as Hexane	8.67E-02	9.26E-02	8.27E-02	8.50E-02	8.74E-02	9.13E-02	9.14E-02	9.57E-02	9.32E-02	8.95E-02	4.28E-03
		Sum of VOCs	4.80E-02	5.19E-02	4.68E-02	4.66E-02	4.35E-02	4.38E-02	4.35E-02	Ι	4.02E-02	4.55E-02	3.58E-03
		Sum of HAPs	3.87E-02	4.07E-02	3.70E-02	3.69E-02	3.42E-02	3.40E-02	3.34E-02	Ι	3.12E-02	3.58E-02	3.12E-03
		Sum of POMs	1.47E-03	2.62E-03	1.76E-03	1.79E-03	1.93E-03	1.59E-03	1.63E-03	Ι	1.39E-03	1.77E-03	3.84E-04
						Individual	Organic H	APs					
х		Benzene	1.82E-02	1.91E-02	1.79E-02	1.77E-02	1.41E-02	1.59E-02	1.59E-02	Ι	1.52E-02	1.67E-02	1.72E-03
х		Toluene	6.43E-03	6.50E-03	6.13E-03	5.83E-03	5.42E-03	5.89E-03	5.44E-03	Ι	5.14E-03	5.85E-03	4.94E-04
х		m,p-Xylene	4.50E-03	4.31E-03	3.71E-03	4.18E-03	3.92E-03	3.66E-03	3.47E-03	Ι	3.08E-03	3.85E-03	4.71E-04
х		Acetaldehyde	1.72E-03	1.72E-03	1.63E-03	1.52E-03	1.65E-03	1.61E-03	1.44E-03	1.70E-03	1.78E-03	1.64E-03	1.08E-04
х		Hexane	1.55E-03	1.37E-03	1.35E-03	1.35E-03	2.66E-03	1.31E-03	1.28E-03	Ι	4.58E-04	1.42E-03	6.00E-04
х		o-Xylene	1.47E-03	1.53E-03	1.42E-03	1.39E-03	1.30E-03	1.38E-03	1.34E-03	Ι	1.29E-03	1.39E-03	8.36E-05
х	z	Naphthalene	1.09E-03	1.87E-03	1.32E-03	1.36E-03	1.45E-03	1.19E-03	1.22E-03	Ι	1.04E-03	1.32E-03	2.60E-04
х		Formaldehyde	1.05E-03	1.05E-03	9.61E-04	9.04E-04	1.10E-03	8.51E-04	7.70E-04	9.14E-04	9.90E-04	9.55E-04	1.06E-04
х		Ethylbenzene	9.44E-04	9.35E-04	8.30E-04	9.03E-04	8.29E-04	7.94E-04	7.90E-04	Ι	7.24E-04	8.44E-04	7.76E-05
х		Styrene	5.27E-04	6.47E-04	5.47E-04	5.69E-04	5.21E-04	5.34E-04	5.16E-04	Ι	5.31E-04	5.49E-04	4.28E-05
x		Propionaldehyde	3.54E-04	3.54E-04	3.08E-04	3.29E-04	3.35E-04	3.47E-04	3.14E-04	3.85E-04	3.95E-04	3.47E-04	2.94E-05
х		Phenol	3.67E-04	3.91E-04	3.25E-04	3.31E-04	3.31E-04	ND	3.51E-04	Ι	ND	2.62E-04	1.63E-04
х	z	2-Methylnaphthalene	2.09E-04	4.46E-04	2.48E-04	2.43E-04	2.63E-04	2.21E-04	2.24E-04	Ι	1.96E-04	2.56E-04	7.96E-05
х	z	1-Methylnaphthalene	1.66E-04	3.07E-04	1.93E-04	1.88E-04	2.15E-04	1.77E-04	1.83E-04	Ι	1.53E-04	1.98E-04	4.80E-05
x		2-Butanone	1.60E-04	1.60E-04	1.71E-04	1.54E-04	1.53E-04	1.51E-04	1.49E-04	1.64E-04	1.78E-04	1.60E-04	9.69E-06
х		Acrolein	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
x	z	Acenaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
х		Biphenyl	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
х		Cresol, mp-	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
х		Cresol, o-	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
х	z	1,2-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
х	z	1,3-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
х	z	1,5-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
х	z	1,6-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
x	z	1,8-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA
х	z	2,3-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	Ι	ND	ND	NA

Test Plan FI Individual Test Results – Lb/Lb Parting Spray

						1001110							
HAPs	POMs	COMPOUND / SAMPLE NUMBER	FI001	F1002	F1003	FI004	F1005	F1006	FI007	F1008	F1009	Average	STDEV
		Test Dates	7/14/03	7/14/03	7/15/03	7/15/03	7/15/03	7/16/03	7/16/03	7/16/03	7/17/03		
х	Z	2,6-Dimethylnaphthalene	ND	Ι	ND	ND	NA						
х	Z	2,7-Dimethylnaphthalene	ND	Ι	ND	ND	NA						
х	z	2,3,5-Trimethylnaphthalene	ND	Ι	ND	ND	NA						
						Othe	er VOCs						
		Heptane	2.27E-03	2.18E-03	2.37E-03	2.47E-03	2.26E-03	2.49E-03	2.72E-03	Ι	2.50E-03	2.41E-03	1.72E-04
		Tetradecane	1.30E-03	2.64E-03	1.65E-03	1.65E-03	1.86E-03	1.46E-03	1.70E-03	Ι	1.47E-03	1.72E-03	4.10E-04
		1,2,4-Trimethylbenzene	1.43E-03	1.75E-03	1.65E-03	1.59E-03	1.46E-03	1.68E-03	1.55E-03	Ι	1.48E-03	1.58E-03	1.14E-04
		Octane	1.20E-03	1.18E-03	1.18E-03	1.22E-03	1.15E-03	1.22E-03	1.26E-03	Ι	1.18E-03	1.20E-03	3.35E-05
		3-Ethyltoluene	8.61E-04	9.15E-04	7.60E-04	7.73E-04	7.73E-04	7.28E-04	8.18E-04	Ι	6.54E-04	7.85E-04	8.02E-05
		1,3,5-Trimethylbenzene	4.54E-04	5.17E-04	4.74E-04	4.53E-04	4.37E-04	4.72E-04	4.77E-04	Ι	3.99E-04	4.60E-04	3.44E-05
		1,2,3-Trimethylbenzene	3.63E-04	4.51E-04	3.82E-04	3.83E-04	3.88E-04	3.91E-04	3.86E-04	Ι	3.44E-04	3.86E-04	3.04E-05
		Indene	4.18E-04	4.98E-04	4.30E-04	4.04E-04	4.20E-04	3.99E-04	3.68E-04	Ι	ND	3.67E-04	1.53E-04
		Benzaldehyde	2.09E-04	2.09E-04	1.73E-04	1.94E-04	1.97E-04	1.90E-04	2.01E-04	1.94E-04	2.31E-04	2.00E-04	1.58E-05
		Butyraldehyde/Methacrolein	1.96E-04	1.96E-04	1.81E-04	1.88E-04	1.90E-04	1.89E-04	1.76E-04	2.04E-04	2.22E-04	1.93E-04	1.36E-05
		2-Ethyltoluene	2.02E-04	2.29E-04	2.03E-04	1.99E-04	ND	2.02E-04	2.11E-04	Ι	1.88E-04	1.79E-04	7.34E-05
		Pentanal	1.08E-04	1.08E-04	9.86E-05	1.02E-04	9.93E-05	9.58E-05	9.22E-05	1.08E-04	1.07E-04	1.02E-04	6.13E-06
		Hexaldehyde	9.61E-05	9.61E-05	7.15E-05	8.69E-05	8.16E-05	7.93E-05	8.87E-05	8.94E-05	8.89E-05	8.65E-05	7.95E-06
		Undecane	1.48E-04	7.24E-05	ND	ND	ND	1.32E-04	1.28E-04	Ι	1.09E-04	7.37E-05	6.48E-05
		Indan	ND	1.88E-04	ND	ND	ND	ND	ND	Ι	ND	2.35E-05	6.64E-05
		o,m,p-Tolualdehyde	ND	ND	1.91E-04	ND	ND	ND	ND	ND	ND	2.13E-05	6.38E-05
		Crotonaldehyde	ND	NA									
		Cyclohexane	ND	Ι	ND	ND	NA						
		Decane	ND	Ι	ND	ND	NA						
		1,3-Diethylbenzene	ND	Ι	ND	ND	NA						
		2,4-Dimethylphenol	ND	Ι	ND	ND	NA						
		2,6-Dimethylphenol	ND	Ι	ND	ND	NA						
		Dodecane	ND	Ι	ND	ND	NA						
		Nonane	ND	Ι	ND	ND	NA						
		Propylbenzene	ND	Ι	ND	ND	NA						

Test Plan FI Individual Test Results – Lb/Lb Parting Spray

HAPs	POMs	COMPOUND / SAMPLE NUMBER	FI001	FI002	FI003	FI004	F1005	FI006	FI007	FI008	F1009	Average	STDEV
		Test Dates	7/14/03	7/14/03	7/15/03	7/15/03	7/15/03	7/16/03	7/16/03	7/16/03	7/17/03		
	Other Analytes												
		Acetone	1.02E-03	1.02E-03	9.44E-04	9.47E-04	9.02E-04	9.09E-04	9.45E-04	9.20E-04	1.03E-03	9.60E-04	5.05E-05
		Carbon Dioxide	1.09E+01	9.78E+00	1.07E+01	1.01E+01	9.77E+00	1.08E+01	1.06E+01	1.01E+01	9.80E+00	1.03E+01	4.79E-01
		Methane	9.95E-03	1.68E-02	1.70E-02	1.64E-02	1.92E-02	1.71E-02	1.83E-02	1.70E-02	1.93E-02	1.68E-02	2.77E-03
		Carbon Monoxide	ND	NA									
		Ethane	ND	NA									
		Propane	ND	NA									
		Isobutane	ND	NA									
		Butane	ND	NA									
		Neopentane	ND	NA									
		Isopentane	ND	NA									
		Pentane	ND	NA									

Test Plan FI Individual Test Results – Lb/Lb Parting Spray

I: Data rejected based on data validation considerations.

ND: Non Detec; NA: Not Applicable

All "Other Analytes" are not included in the Sum of HAPs or VOCs.

HAPs	POMs	COMPOUND / SAMPLE NUMBER	FJ001	FJ002	FJ003	FJ004	FJ005	FJ006	FJ007	FJ008	FJ009	Average	STDEV
		Test Dates	7/29/03	7/29/03	7/29/03	7/30/03	7/30/03	7/30/03	7/31/03	7/31/03	7/31/03		
		TGOC as Propane	6.35E-01	7.35E-01	7.87E-01	7.88E-01	7.33E-01	8.18E-01	7.35E-01	7.13E-01	6.90E-01	7.37E-01	5.60E-02
		HC as Hexane	1.02E-01	1.27E-01	1.22E-01	1.24E-01	1.22E-01	1.25E-01	9.87E-02	1.21E-01	1.21E-01	1.18E-01	1.02E-02
		Sum of VOCs	7.05E-02	8.39E-02	8.07E-02	8.29E-02	8.31E-02	Ι	8.33E-02	8.93E-02	8.43E-02	8.23E-02	5.34E-03
		Sum of HAPs	6.33E-02	7.38E-02	7.15E-02	7.42E-02	7.40E-02	Ι	7.30E-02	7.73E-02	7.19E-02	7.24E-02	4.07E-03
		Sum of POMs	2.62E-03	2.93E-03	2.99E-03	2.32E-03	2.81E-03	3.76E-03	2.74E-03	3.17E-03	3.60E-03	2.99E-03	4.59E-04
						Individual	Organic HA	Ps					
x		Benzene	3.58E-02	4.25E-02	4.06E-02	4.34E-02	4.23E-02	Ι	3.98E-02	4.42E-02	3.97E-02	4.10E-02	2.68E-03
x		Toluene	8.80E-03	9.47E-03	9.74E-03	1.04E-02	1.15E-02	Ι	1.09E-02	1.10E-02	1.03E-02	1.03E-02	8.79E-04
x		m,p-Xylene	4.60E-03	5.16E-03	5.09E-03	5.39E-03	5.61E-03	6.55E-03	5.76E-03	5.99E-03	5.80E-03	5.55E-03	5.70E-04
x		Acetaldehyde	2.91E-03	3.38E-03	3.31E-03	2.96E-03	3.17E-03	3.63E-03	3.41E-03	3.52E-03	3.33E-03	3.29E-03	2.40E-04
x	Z	Naphthalene	2.18E-03	2.42E-03	2.53E-03	2.10E-03	2.38E-03	3.21E-03	2.31E-03	2.73E-03	3.02E-03	2.54E-03	3.74E-04
x		o-Xylene	1.92E-03	2.20E-03	2.15E-03	2.32E-03	2.42E-03	2.79E-03	2.47E-03	2.53E-03	2.54E-03	2.37E-03	2.54E-04
x		Hexane	1.69E-03	1.90E-03	1.87E-03	2.17E-03	9.56E-04	1.10E-03	2.50E-03	9.64E-04	9.47E-04	1.57E-03	5.90E-04
x		Styrene	1.43E-03	1.60E-03	1.49E-03	1.60E-03	1.55E-03	Ι	1.49E-03	1.50E-03	1.53E-03	1.52E-03	5.75E-05
x		Ethylbenzene	1.17E-03	1.32E-03	1.30E-03	1.36E-03	1.43E-03	1.67E-03	1.43E-03	1.59E-03	1.49E-03	1.42E-03	1.52E-04
x		Formaldehyde	1.29E-03	1.97E-03	1.69E-03	1.11E-03	1.31E-03	1.36E-03	1.26E-03	1.33E-03	1.29E-03	1.40E-03	2.63E-04
x		Propionaldehyde	8.70E-04	1.08E-03	9.97E-04	9.97E-04	1.01E-03	1.18E-03	1.07E-03	1.22E-03	1.10E-03	1.06E-03	1.04E-04
x	Z	2-Methylnaphthalene	2.46E-04	2.39E-04	2.53E-04	2.12E-04	2.36E-04	3.04E-04	2.34E-04	2.40E-04	3.19E-04	2.54E-04	3.49E-05
x		2-Butanone	1.98E-04	2.58E-04	2.46E-04	2.29E-04	Ι	2.79E-04	2.54E-04	2.84E-04	2.60E-04	2.51E-04	2.75E-05
x	Z	1-Methylnaphthalene	1.85E-04	2.77E-04	2.04E-04	Ι	1.92E-04	2.46E-04	1.92E-04	2.01E-04	2.64E-04	2.20E-04	3.64E-05
x	Z	1,2-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
x	Z	1,3-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X	Z	1,5-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X	Z	1,6-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X	Z	1,8-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X	Z	2,3,5-Trimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X	Z	2,3-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X	Z	2,6-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X	Z	2,7-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X	Z	Acenaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X		Biphenyl	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X		m,p-Cresol	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X		Phenol	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X		Acrolein	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
X		o-Cresol	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA

HAPs	Ž COMPOUND / SAMPLE NUMBER	FJ001	FJ002	FJ003	FJ004	FJ005	FJ006	FJ007	FJ008	FJ009	Average	STDEV
	Test Dates	7/29/03	7/29/03	7/29/03	7/30/03	7/30/03	7/30/03	7/31/03	7/31/03	7/31/03		
					Othe	r VOCs						
	1,2,4-Trimethylbenzene	1.71E-03	1.82E-03	1.84E-03	1.93E-03	2.07E-03	2.48E-03	2.18E-03	2.21E-03	2.31E-03	2.06E-03	2.54E-04
-	Heptane	6.39E-04	1.91E-03	1.93E-03	1.18E-03	1.24E-03	1.44E-03	2.50E-03	2.83E-03	2.70E-03	1.82E-03	7.55E-04
	Octane	1.40E-03	1.56E-03	1.57E-03	1.75E-03	1.86E-03	2.13E-03	1.96E-03	1.98E-03	2.08E-03	1.81E-03	2.54E-04
	Indene	1.07E-03	1.30E-03	1.15E-03	1.17E-03	1.11E-03	Ι	1.09E-03	1.19E-03	1.18E-03	1.16E-03	7.37E-05
	3-Ethyltoluene	8.04E-04	9.14E-04	8.89E-04	9.34E-04	9.95E-04	1.19E-03	1.17E-03	1.09E-03	1.10E-03	1.01E-03	1.34E-04
	1,3,5-Trimethylbenzene	4.79E-04	5.40E-04	5.13E-04	5.02E-04	5.27E-04	6.38E-04	Ι	5.48E-04	5.95E-04	5.43E-04	5.17E-05
-	1,2,3-Trimethylbenzene	3.78E-04	4.35E-04	4.04E-04	4.21E-04	4.58E-04	5.61E-04	4.86E-04	4.98E-04	5.36E-04	4.64E-04	6.14E-05
	Butyraldehyde/Methacrolein	3.92E-04	4.48E-04	4.20E-04	3.92E-04	4.07E-04	4.68E-04	4.43E-04	4.33E-04	4.26E-04	4.25E-04	2.56E-05
	Tetradecane	ND	5.93E-04	ND	ND	ND	7.02E-04	ND	6.42E-04	8.85E-04	3.13E-04	3.80E-04
	Hexaldehyde	1.71E-04	2.08E-04	2.17E-04	2.72E-04	2.46E-04	2.30E-04	2.94E-04	2.88E-04	2.81E-04	2.45E-04	4.20E-05
	Pentanal	Ι	1.64E-04	1.73E-04	1.67E-04	1.66E-04	1.81E-04	1.81E-04	1.99E-04	1.99E-04	1.79E-04	1.40E-05
	Benzaldehyde	1.57E-04	1.65E-04	1.34E-04	ND	ND	1.23E-04	ND	1.19E-04	1.20E-04	9.08E-05	6.99E-05
	1,3-Diethylbenzene	ND	NA									
	2,4-Dimethylphenol	ND	NA									
	2,6-Dimethylphenol	ND	NA									
	2-Ethyltoluene	ND	NA									
	Cyclohexane	ND	NA									
	Decane	ND	NA									
	Dodecane	ND	NA									
	Indan	ND	NA									
	Nonane	ND	NA									
	n-Propylbenzene	ND	NA									
	Undecane	ND	Ι	ND	NA							
	Crotonaldehyde	ND	NA									
	o,m,p-Tolualdehyde	ND	NA									

Test Plan FJ Individual Test Results – Lb/Tn Metal

HAPs	POMs	COMPOUND / SAMPLE NUMBER	FJ001	FJ002	FJ003	FJ004	FJ005	FJ006	FJ007	FJ008	FJ009	Average	STDEV
		Test Dates	7/29/03	7/29/03	7/29/03	7/30/03	7/30/03	7/30/03	7/31/03	7/31/03	7/31/03		
	Other Analytes												
		Acetone	1.46E-03	1.81E-03	1.88E-03	1.50E-03	1.44E-03	1.76E-03	1.59E-03	1.69E-03	1.74E-03	1.65E-03	1.60E-04
		Carbon Dioxide	1.97E+01	1.97E+01	1.83E+01	2.05E+01	1.93E+01	1.95E+01	1.86E+01	1.78E+01	1.74E+01	1.90E+01	1.02E+00
		Methane	2.62E-02	3.59E-02	2.88E-02	3.25E-02	3.79E-02	3.37E-02	3.57E-02	3.57E-02	3.43E-02	3.34E-02	3.73E-03
		Carbon Monoxide	ND	NA									
		Ethane	ND	NA									
		Propane	ND	NA									
		Isobutane	ND	NA									
		Butane	ND	NA									
		Neopentane	ND	NA									
		Isopentane	ND	NA									
		Pentane	ND	NA									

Test Plan FJ Individual Test Results – Lb/Tn Metal

I: Data rejected based on data validation considerations.

ND: Non Detect; NA: Not Applicable

All "Other Analytes" are not included in the Sum of HAPs or VOCs.

HAPs	POMs	COMPOUND / SAMPLE NUMBER	FJ001	FJ002	FJ003	FJ004	FJ005	FJ006	FJ007	FJ008	FJ009	Average	STDEV
		Test Dates	7/29/03	7/29/03	7/29/03	7/30/03	7/30/03	7/30/03	7/31/03	7/31/03	7/31/03		
		TGOC as Propane	3.58E-01	3.65E-01	4.01E-01	3.96E-01	4.01E-01	4.25E-01	3.98E-01	4.05E-01	3.88E-01	3.93E-01	2.04E-02
		HC as Hexane	5.77E-02	5.77E-02	6.22E-02	5.95E-02	6.44E-02	6.60E-02	5.35E-02	6.86E-02	6.82E-02	6.20E-02	5.23E-03
		Sum of VOCs	3.97E-02	4.21E-02	4.11E-02	4.12E-02	4.53E-02	Ι	4.50E-02	5.05E-02	4.73E-02	4.40E-02	3.65E-03
		Sum of HAPs	3.57E-02	3.71E-02	3.64E-02	3.69E-02	4.04E-02	Ι	3.95E-02	4.37E-02	4.03E-02	3.87E-02	2.70E-03
		Sum of POMs	1.48E-03	1.85E-03	1.53E-03	1.16E-03	1.54E-03	1.94E-03	1.48E-03	1.80E-03	2.02E-03	1.65E-03	2.77E-04
						Individual	Organic H	APs					
х		Benzene	2.02E-02	2.12E-02	2.08E-02	2.17E-02	2.32E-02	Ι	2.15E-02	2.50E-02	2.24E-02	2.20E-02	1.53E-03
х		Toluene	4.97E-03	4.71E-03	4.98E-03	5.19E-03	6.28E-03	Ι	5.90E-03	6.23E-03	5.78E-03	5.51E-03	6.15E-04
х		m,p-Xylene	2.60E-03	2.57E-03	2.60E-03	2.69E-03	3.08E-03	3.39E-03	3.12E-03	3.39E-03	3.26E-03	2.97E-03	3.50E-04
х		Acetaldehyde	1.59E-03	1.67E-03	1.63E-03	1.38E-03	1.62E-03	1.86E-03	1.79E-03	1.93E-03	1.81E-03	1.70E-03	1.68E-04
х	Z	Naphthalene	1.23E-03	1.54E-03	1.30E-03	1.05E-03	1.31E-03	1.66E-03	1.25E-03	1.55E-03	1.70E-03	1.40E-03	2.20E-04
х		o-Xylene	1.09E-03	1.09E-03	1.10E-03	1.16E-03	1.32E-03	1.44E-03	1.34E-03	1.43E-03	1.43E-03	1.27E-03	1.56E-04
x		Hexane	9.56E-04	9.47E-04	9.56E-04	1.08E-03	5.24E-04	5.70E-04	1.35E-03	5.46E-04	5.33E-04	8.30E-04	2.99E-04
х		Styrene	8.09E-04	7.94E-04	7.61E-04	7.99E-04	8.51E-04	I	8.07E-04	8.51E-04	8.59E-04	8.16E-04	3.42E-05
х		Ethylbenzene	6.62E-04	6.59E-04	6.63E-04	6.81E-04	7.86E-04	8.63E-04	7.76E-04	9.00E-04	8.38E-04	7.59E-04	9.51E-05
х		Formaldehyde	7.08E-04	9.72E-04	8.33E-04	5.15E-04	6.71E-04	6.95E-04	6.59E-04	7.34E-04	7.00E-04	7.21E-04	1.25E-04
х		Propionaldehyde	4.77E-04	5.30E-04	4.92E-04	4.64E-04	5.20E-04	6.01E-04	5.61E-04	6.72E-04	5.96E-04	5.46E-04	6.79E-05
х	Z	2-Methylnaphthalene	1.39E-04	1.72E-04	1.30E-04	1.06E-04	1.29E-04	1.57E-04	1.27E-04	1.36E-04	1.79E-04	1.42E-04	2.35E-05
х		2-Butanone	1.09E-04	1.27E-04	1.22E-04	1.07E-04	Ι	1.43E-04	1.33E-04	1.56E-04	1.41E-04	1.30E-04	1.71E-05
х	Z	1-Methylnaphthalene	1.05E-04	1.38E-04	1.04E-04	I	1.05E-04	1.27E-04	1.04E-04	1.14E-04	1.49E-04	1.18E-04	1.75E-05
х	Z	Acenaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х		Biphenyl	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х		m,p-Cresol	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х		o-Cresol	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
x	Z	1,2-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
Х	Z	1,3-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х	Z	1,5-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
Х	Z	1,6-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х	Z	1,8-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х	Z	2,3-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х	Z	2,6-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х	Z	2,7-Dimethylnaphthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
Х		Phenol	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х	Z	2,3,5-Trimethylnapthalene	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA
х		Acrolein	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NA

Test Plan FJ Individual Test Results – Lb/Lb Parting Spray

HAPs	کے COMPOUND / SAMPLE NUMBER	FJ001	FJ002	FJ003	FJ004	FJ005	FJ006	FJ007	FJ008	FJ009	Average	STDEV
	Test Dates	7/29/03	7/29/03	7/29/03	7/30/03	7/30/03	7/30/03	7/31/03	7/31/03	7/31/03		
					Oth	er VOCs						
	1,2,4-Trimethylbenzene	9.66E-04	9.07E-04	9.42E-04	9.65E-04	1.13E-03	1.28E-03	1.18E-03	1.25E-03	1.30E-03	1.10E-03	1.59E-04
	Heptane	3.61E-04	9.51E-04	9.86E-04	5.88E-04	6.82E-04	7.43E-04	1.35E-03	1.60E-03	1.52E-03	9.76E-04	4.33E-04
	Octane	7.91E-04	7.78E-04	8.01E-04	8.75E-04	1.02E-03	1.10E-03	1.06E-03	1.12E-03	1.17E-03	9.68E-04	1.57E-04
	Indene	6.05E-04	6.49E-04	5.86E-04	5.85E-04	6.07E-04	Ι	5.93E-04	6.76E-04	6.66E-04	6.21E-04	3.70E-05
	3-Ethyltoluene	4.55E-04	4.55E-04	4.54E-04	4.67E-04	5.46E-04	6.16E-04	6.32E-04	6.20E-04	6.17E-04	5.40E-04	8.19E-05
	1,3,5-Trimethylbenzene	2.71E-04	2.69E-04	2.62E-04	2.51E-04	2.89E-04	3.30E-04	Ι	3.11E-04	3.35E-04	2.90E-04	3.19E-05
	1,2,3-Trimethylbenzene	2.14E-04	2.16E-04	2.06E-04	2.10E-04	2.51E-04	2.90E-04	2.63E-04	2.83E-04	3.02E-04	2.48E-04	3.78E-05
	Butyraldehyde/Methacrolein	2.15E-04	2.21E-04	2.07E-04	1.83E-04	2.09E-04	2.39E-04	2.32E-04	2.38E-04	2.31E-04	2.19E-04	1.83E-05
	Tetradecane	ND	2.95E-04	ND	ND	ND	3.63E-04	ND	3.64E-04	4.98E-04	1.69E-04	2.07E-04
	Hexaldehyde	9.40E-05	1.02E-04	1.07E-04	1.26E-04	1.26E-04	1.18E-04	1.54E-04	1.59E-04	1.53E-04	1.27E-04	2.39E-05
	Pentanal	Ι	8.08E-05	8.55E-05	7.78E-05	8.51E-05	9.24E-05	9.50E-05	1.09E-04	1.08E-04	9.17E-05	1.19E-05
	Benzaldehyde	8.60E-05	8.14E-05	6.60E-05	ND	ND	6.30E-05	ND	6.52E-05	6.54E-05	4.74E-05	3.64E-05
	o,m,p-Tolualdehyde	ND	NA									
	Cyclohexane	ND	NA									
	Decane	ND	NA									
	1,3-Diethylbenzene	ND	NA									
	2,4-Dimethylphenol	ND	NA									
	2,6-Dimethylphenol	ND	NA									
	Dodecane	ND	NA									
	2-Ethyltoluene	ND	NA									
	Indan	ND	NA									
	Nonane	ND	NA									
	Propylbenzene	ND	NA									
	Undecane	ND	Ι	ND	NA							
	Crotonaldehyde	ND	NA									

Test Plan FJ Individual Test Results – Lb/Lb Parting Spray

HAPs	POMs	COMPOUND / SAMPLE NUMBER	FJ001	FJ002	FJ003	FJ004	FJ005	FJ006	FJ007	FJ008	FJ009	Average	STDEV
		Test Dates	7/29/03	7/29/03	7/29/03	7/30/03	7/30/03	7/30/03	7/31/03	7/31/03	7/31/03		
	Other Analytes												
		Acetone	8.00E-04	8.90E-04	9.28E-04	6.99E-04	7.36E-04	9.00E-04	8.35E-04	9.28E-04	9.43E-04	8.51E-04	8.89E-05
		Carbon Dioxide	1.11E+01	9.82E+00	9.35E+00	1.06E+01	1.00E+01	1.02E+01	1.02E+01	1.01E+01	9.59E+00	1.01E+01	5.31E-01
		Methane	1.48E-02	1.79E-02	1.47E-02	1.68E-02	1.96E-02	1.76E-02	1.95E-02	2.02E-02	1.88E-02	1.78E-02	2.03E-03
		Carbon Monoxide	ND	NA									
		Ethane	ND	NA									
		Propane	ND	NA									
		Isobutane	ND	NA									
		Butane	ND	NA									
		Neopentane	ND	NA									
		Isopentane	ND	NA									
		Pentane	ND	NA									

Test Plan FJ Individual Test Results – Lb/Lb Parting Spray

I: Data rejected based on data validation considerations.

ND: Non Detect; NA: Not Applicable

All "Other Analytes" are not included in the Sum of HAPs or VOCs.

Test Plan FI Quantitation Limits – Lb/Tn Metal

Analytes	Lb/Tn Metal
1,2,3-Trimethylbenzene	1.31E-04
1,2,4-Trimethylbenzene	1.31E-04
1,3,5-Trimethylbenzene	1.31E-04
1,3-Dimethylnaphthalene	1.31E-04
1-Methylnaphthalene	1.31E-04
2-Ethyltoluene	1.31E-04
2-Methylnaphthalene	1.31E-04
Benzene	1.31E-04
Ethylbenzene	1.31E-04
Hexane	1.31E-04
m,p-Xylene	1.31E-04
Naphthalene	1.31E-04
o-Xylene	1.31E-04
Styrene	1.31E-04
Toluene	1.31E-04
Undecane	1.31E-04
1,2-Dimethylnaphthalene	6.55E-04
1,3-Diethylbenzene	6.55E-04
1,5-Dimethylnaphthalene	6.55E-04
1,6-Dimethylnaphthalene	6.55E-04
1,8-Dimethylnaphthalene	6.55E-04
2,3,5-Trimethylnaphthalene	6.55E-04
2,3-Dimethylnaphthalene	6.55E-04
2,4-Dimethylphenol	6.55E-04
2,6-Dimethylnaphthalene	6.55E-04
2,6-Dimethylphenol	6.55E-04
2,7- Dimethylnaphthalene	6.55E-04
3-Ethyltoluene	6.55E-04
Acenaphthalene	6.55E-04

Analytes	Lb/Tn Metal
Biphenyl	6.55E-04
Cyclohexane	6.55E-04
Decane	6.55E-04
Dodecane	6.55E-04
Heptane	6.55E-04
Indan	6.55E-04
Indene	6.55E-04
m,p-Cresol	6.55E-04
Nonane	6.55E-04
o-Cresol	6.55E-04
Octane	6.55E-04
Phenol	6.55E-04
Propylbenzene	6.55E-04
Tetradecane	6.55E-04
2-Butanone (MEK)	1.14E-04
Acetaldehyde	1.14E-04
Acetone	1.14E-04
Acrolein	1.14E-04
Benzaldehyde	1.14E-04
Butyraldehyde	1.14E-04
Crotonaldehyde	1.14E-04
Formaldehyde	1.14E-04
Hexaldehyde	1.14E-04
Butyraldehyde/Methacrolein	1.90E-04
o,m,p-Tolualdehyde	3.04E-04
Pentanal (Valeraldehyde)	1.14E-04
Propionaldehyde (Propanal)	1.14E-04
HC as Hexane	3.67E-03

Analytes	Lb/Tn Metal
Carbon Monoxide	3.09E-01
Methane	1.76E-02
Carbon Dioxide	4.85E-01
Ethane	3.31E-01
Propane	4.85E-01
Isobutane	6.39E-01
Butane	6.39E-01
Neopentane	7.94E-01
Isopentane	7.94E-01
Pentane	7.94E-01

Test Plan FI Quantitation Limits – Lb/Lb Parting Sp	oray
---	------

Analytes	Lb/Lb Parting Spray
1,2,3-Trimethylbenzene	7.13E-05
1,2,4-Trimethylbenzene	7.13E-05
1,3,5-Trimethylbenzene	7.13E-05
1,3-Dimethylnaphthalene	7.13E-05
1-Methylnaphthalene	7.13E-05
2-Ethyltoluene	7.13E-05
2-Methylnaphthalene	7.13E-05
Benzene	7.13E-05
Ethylbenzene	7.13E-05
Hexane	7.13E-05
m,p-Xylene	7.13E-05
Naphthalene	7.13E-05
o-Xylene	7.13E-05
Styrene	7.13E-05
Toluene	7.13E-05
Undecane	7.13E-05
1,2-Dimethylnaphthalene	3.56E-04
1,3-Diethylbenzene	3.56E-04
1,5-Dimethylnaphthalene	3.56E-04
1,6-Dimethylnaphthalene	3.56E-04
1,8-Dimethylnaphthalene	3.56E-04
2,3,5-Trimethylnaphthalene	3.56E-04
2,3-Dimethylnaphthalene	3.56E-04
2,4-Dimethylphenol	3.56E-04
2,6-Dimethylnaphthalene	3.56E-04
2,6-Dimethylphenol	3.56E-04
2,7- Dimethylnaphthalene	3.56E-04
3-Ethyltoluene	3.56E-04
Acenaphthalene	3.56E-04

Analytes	Lb/Lb Parting Spray
Biphenyl	3.56E-04
Cyclohexane	3.56E-04
Decane	3.56E-04
Dodecane	3.56E-04
Heptane	3.56E-04
Indan	3.56E-04
Indene	3.56E-04
m,p-Cresol	3.56E-04
Nonane	3.56E-04
o-Cresol	3.56E-04
Octane	3.56E-04
Phenol	3.56E-04
Propylbenzene	3.56E-04
Tetradecane	3.56E-04
2-Butanone (MEK)	6.19E-05
Acetaldehyde	6.19E-05
Acetone	6.19E-05
Acrolein	6.19E-05
Benzaldehyde	6.19E-05
Butyraldehyde	6.19E-05
Crotonaldehyde	6.19E-05
Formaldehyde	6.19E-05
Hexaldehyde	6.19E-05
Butyraldehyde/Methacrolein	1.03E-04
o,m,p-Tolualdehyde	1.65E-04
Pentanal (Valeraldehyde)	6.19E-05
Propionaldehyde (Propanal)	6.19E-05
HC as Hexane	2.00E-03

Analytes	Lb/Lb Parting Spray
Carbon Monoxide	1.68E-01
Methane	9.59E-03
Carbon Dioxide	2.64E-01
Ethane	1.80E-01
Propane	2.64E-01
Isobutane	3.48E-01
Butane	3.48E-01
Neopentane	4.32E-01
Isopentane	4.32E-01
Pentane	4.32E-01

Test Plan FJ Quantitation Limits – Lb/Tn Metal

Analytes	Lb/Tn Metal
1,2,3-Trimethylbenzene	1.30E-04
1,2,4-Trimethylbenzene	1.30E-04
1,3,5-Trimethylbenzene	1.30E-04
1,3-Dimethylnaphthalene	1.30E-04
1-Methylnaphthalene	1.30E-04
2-Ethyltoluene	1.30E-04
2-Methylnaphthalene	1.30E-04
Benzene	1.30E-04
Ethylbenzene	1.30E-04
Hexane	1.30E-04
m,p-Xylene	1.30E-04
Naphthalene	1.30E-04
o-Xylene	1.30E-04
Styrene	1.30E-04
Toluene	1.30E-04
Undecane	1.30E-04
1,2-Dimethylnaphthalene	6.50E-04
1,3-Diethylbenzene	6.50E-04
1,5-Dimethylnaphthalene	6.50E-04
1,6-Dimethylnaphthalene	6.50E-04
1,8-Dimethylnaphthalene	6.50E-04
2,3,5-Trimethylnaphthalene	6.50E-04
2,3-Dimethylnaphthalene	6.50E-04
2,4-Dimethylphenol	6.50E-04
2,6-Dimethylnaphthalene	6.50E-04
2,6-Dimethylphenol	6.50E-04
2,7- Dimethylnaphthalene	6.50E-04
3-Ethyltoluene	6.50E-04
Acenaphthalene	6.50E-04

Analytes	Lb/Tn Metal
Biphenyl	6.50E-04
Cyclohexane	6.50E-04
Decane	6.50E-04
Dodecane	6.50E-04
Heptane	6.50E-04
Indan	6.50E-04
Indene	6.50E-04
m,p-Cresol	6.50E-04
Nonane	6.50E-04
o-Cresol	6.50E-04
Octane	6.50E-04
Phenol	6.50E-04
Propylbenzene	6.50E-04
Tetradecane	6.50E-04
2-Butanone (MEK)	1.15E-04
Acetaldehyde	1.15E-04
Acetone	1.15E-04
Acrolein	1.15E-04
Benzaldehyde	1.15E-04
Butyraldehyde	1.15E-04
Crotonaldehyde	1.15E-04
Formaldehyde	1.15E-04
Hexaldehyde	1.15E-04
Butyraldehyde/Methacrolein	1.91E-04
o,m,p-Tolualdehyde	3.06E-04
Pentanal (Valeraldehyde)	1.15E-04
Propionaldehyde (Propanal)	1.15E-04
HC as Hexane	3.70E-03

Analytes	Lb/Tn Metal
Carbon Monoxide	3.13E-01
Methane	1.79E-02
Carbon Dioxide	4.92E-01
Ethane	3.35E-01
Propane	4.92E-01
Isobutane	6.48E-01
Butane	6.48E-01
Neopentane	8.05E-01
Isopentane	8.05E-01
Pentane	8.05E-01

Test Plan FJ Quantitation Limits – Lb/Tn Metal

Analytes	Lb/Lb Parting Spray
1,2,3-Trimethylbenzene	6.95E-05
1,2,4-Trimethylbenzene	6.95E-05
1,3,5-Trimethylbenzene	6.95E-05
1,3-Dimethylnaphthalene	6.95E-05
1-Methylnaphthalene	6.95E-05
2-Ethyltoluene	6.95E-05
2-Methylnaphthalene	6.95E-05
Benzene	6.95E-05
Ethylbenzene	6.95E-05
Hexane	6.95E-05
m,p-Xylene	6.95E-05
Naphthalene	6.95E-05
o-Xylene	6.95E-05
Styrene	6.95E-05
Toluene	6.95E-05
Undecane	6.95E-05
1,2-Dimethylnaphthalene	3.47E-04
1,3-Diethylbenzene	3.47E-04
1,5-Dimethylnaphthalene	3.47E-04
1,6-Dimethylnaphthalene	3.47E-04
1,8-Dimethylnaphthalene	3.47E-04
2,3,5-Trimethylnaphthalene	3.47E-04
2,3-Dimethylnaphthalene	3.47E-04
2,4-Dimethylphenol	3.47E-04
2,6-Dimethylnaphthalene	3.47E-04
2,6-Dimethylphenol	3.47E-04
2,7- Dimethylnaphthalene	3.47E-04
3-Ethyltoluene	3.47E-04
Acenaphthalene	3.47E-04

Analytes	Lb/Lb Parting Spray
Biphenyl	3.47E-04
Cyclohexane	3.47E-04
Decane	3.47E-04
Dodecane	3.47E-04
Heptane	3.47E-04
Indan	3.47E-04
Indene	3.47E-04
m,p-Cresol	3.47E-04
Nonane	3.47E-04
o-Cresol	3.47E-04
Octane	3.47E-04
Phenol	3.47E-04
Propylbenzene	3.47E-04
Tetradecane	3.47E-04
2-Butanone (MEK)	6.14E-05
Acetaldehyde	6.14E-05
Acetone	6.14E-05
Acrolein	6.14E-05
Benzaldehyde	6.14E-05
Butyraldehyde	6.14E-05
Crotonaldehyde	6.14E-05
Formaldehyde	6.14E-05
Hexaldehyde	6.14E-05
Butyraldehyde/Methacrolein	1.02E-04
o,m,p-Tolualdehyde	1.64E-04
Pentanal (Valeraldehyde)	6.14E-05
Propionaldehyde (Propanal)	6.14E-05
HC as Hexane	1.98E-03

Analytes	Lb/Lb Parting Spray
Carbon Monoxide	1.67E-01
Methane	9.56E-03
Carbon Dioxide	2.63E-01
Ethane	1.79E-01
Propane	2.63E-01
Isobutane	3.47E-01
Butane	3.47E-01
Neopentane	4.30E-01
Isopentane	4.30E-01
Pentane	4.30E-01

FI and FJ Average Test Results with T-Statistics –

	Lb/Tn Met	ai					
Analytes	Test FI (Lb/Tn Metal)	Test FJ (Lb/Tn Metal)	T-Statistic				
TGOC as Propane	0.8651	0.7371	5.22				
HC as Hexane	0.1680	0.1179	10.42				
Sum of VOCs	0.0819	0.0823	-0.13				
Sum of HAPs	0.0643	0.0724	-3.00				
Sum of POMs	0.0030	0.0030	0.00				
Individual Organic HAPs							
Benzene	0.0304	0.0410	-7.07				
Toluene	0.0106	0.0103	0.67				
o,m,p-Xylene	0.0095	0.0079	3.75				
Acetaldehyde	0.0030	0.0033	-2.50				
Formaldehyde	0.0018	0.0014	2.83				
Naphthalene	0.0023	0.0025	-1.20				
Ethylbenzene	0.0015	0.0014	1.06				
Styrene	0.0010	0.0015	-10.61				
Methylnaphthalenes	0.0008	0.0004	8.49				
Hexane	0.0023	0.0016	2.47				
Other VOCs							
Tetradecane	0.0029	0.0003	15.60				
Trimethylbenzenes	0.0044	0.0030	7.42				
Heptane	0.0044	0.0018	9.13				
Octane	0.0022	0.0018	3.79				
Ethyltoluenes	0.0018	0.0010	10.73				
Indene	0.0007	0.0012	-4.74				
Other Analytes							
Carbon Dioxide	18.72	18.99	-0.61				
Methane	0.0306	0.0334	-1.33				

FI and FJ Average Test Results with T-Statistics – Lb/Lb Parting Spray

Analytes	Test FI (Lb/Lb Parting Spray)	Test FJ (Lb/Lb Parting Spray)	T-Statistic				
TGOC as Propane	0.4717	0.3930	8.04				
HC as Hexane	0.0895	0.0620	12.23				
Sum of VOCs	0.0455	0.0440	0.88				
Sum of HAPs	0.0358	0.0387	-2.12				
Sum of POMs	0.0018	0.0016	1.20				
Individual Organic HAPs							
Benzene	0.0167	0.0220	-7.01				
Toluene	0.0058	0.0055	1.15				
o,m,p-Xylene	0.0052	0.0042	4.24				
Acetaldehyde	0.0016	0.0017	-1.34				
Naphthalene	0.0013	0.0014	-0.83				
Hexane	0.0014	0.0008	2.68				
Styrene	0.0005	0.0008	NA				
Ethylbenzene	0.0008	0.0008	0.00				
Formaldehyde	0.0010	0.0007	6.36				
Methylnaphthalenes	0.0005	0.0002	6.36				
(Other VOCs						
Trimethylbenzenes	0.0024	0.0016	8.49				
Heptane	0.0024	0.0010	9.39				
Tetradecane	0.0017	0.0002	10.06				
Octane	0.0012	0.0010	3.00				
Ethyltoluenes	0.0010	0.0005	10.61				
Indene	0.0004	0.0006	-3.00				
Other Analytes							
Methane	0.0168	0.0178	-1.24				
Carbon Dioxide	10.29	10.11	0.74				

APPENDIX C TEST SERIES FI AND FJ DETAILED PROCESS DATA


Greensand PCS										
Pour Date	7/14/2003	7/14/2003	7/15/2003	7/15/2003	7/15/2003	7/16/2003	7/16/2003	7/16/2003	7/17/2003	
Emissions Sample #	FI 001	FI 002	FI 003	FI 004	FI 005	FI 006	FI 007	FI 008	FI 009	Ave rage
Production Sample #	FI 001	FI 002	FI 003	FI 004	FI 005	FI 006	FI 007	FI 008	FI 009	
Cast Weight - All Metal Inside Mold (lbs.)	100.5	96.0	95.0	96.0	99.5	99.5	98.0	96.5	100.5	97.9
Pouring Time (sec.)	19	21	21	20	16	16	13	14	16	17
Pouring Temp (°F)	2679	2688	2673	2679	2690	2689	2680	2675	2689	2682
Pour Hood Process Air Temp at Start of Pour (°F)	87	92	87	87	90	86	87	90	85	88
Muller Batch Weight (lbs.)	970	900	900	900	910	900	900	840	900	902
GS Mold Sand Weight, (lbs.)	656	650	660	656	660	660	656	660	660	658
Mold Compactability, %	49	51	49	48	48	45	48	45	45	48
Mold Temperature (°F)	87	91	86	90	89	83	93	96	83	89
Average Green Compression (psi)	13.50	12.53	12.77	13.69	13.97	13.95	13.40	13.46	14.99	13.58
GS Compactability (%)	43	51	47	45	45	42	44	42	41	44
GS Moisture Content (%)	1.78	1.98	1.88	1.95	2.01	2.00	1.96	1.88	1.80	1.92
GS Clay Content (%)	6.87	6.62	6.87	6.87	7.25	7.64	6.87	6.62	6.87	6.94
1800°F LOI - Mold Sand (%)	1.12	1.19	1.12	1.10	1.13	1.11	1.14	1.04	1.05	1.11
900°F Volatiles (%)	0.53	0.42	0.40	0.38	0.32	0.42	0.36	0.30	0.34	0.39
Liquid Parting Spray (grams)	40	41	40	41	40	40	41	41	41	40.6


Test FI Detailed Process Data


			Greensa	and PCS						
Pour Date	7/29/2003	7/29/2003	7/29/2003	7/30/2003	7/30/2003	7/30/2003	7/31/2003	7/31/2003	7/31/2003	
Emissions Sample #	FJ 001	FJ 002	FJ 003	FJ 004	FJ 005	FJ 006	FJ 007	FJ 008	FJ 009	Average
Production Sample #	FJ 001	FJ 002	FJ 003	FJ 004	FJ 005	FJ 006	FJ 007	FJ 008	FJ 009	
Cast Weight- All Metal Inside Mold (lbs.)	99.5	94.5	92.0	93.0	96.5	92.0	97.5	102.0	99.0	96.2
Pouring Time (sec.)	16	23	20	20	17	25	15	19	17	19
Pouring Temp (°F)	2689	2683	2685	2678	2682	2688	2682	2687	2688	2685
Pour Hood Process Air Temp at Start of Pour (°F)	85	88	95	85	86	88	82	89	91	88
Muller Batch Weight (lbs.)	900	900	900	900	900	900	900	900	870	897
GS Mold Sand Weight (lbs.)	670	666	670	646	660	666	670	656	N/D	663
Mold Compactability (%)	45	46	45	46	45	43	43	45	42	44
Mold Temperature (°F)	81	93	96	86	96	90	81	87	91	89
Average Green Compression (psi)	13.15	12.56	13.23	13.54	13.26	13.91	14.37	13.03	14.62	13.52
GS Compactability (%)	41	38	34	40	43	34	34	33	43	38
GS Moisture Content (%)	1.78	1.76	1.64	1.77	1.98	1.81	1.79	1.83	1.99	1.82
GS Clay Content (%)	7.64	7.13	7.13	7.13	7.38	7.38	7.89	6.87	7.38	7.33
1800°F LOI - Mold Sand (%)	0.98	0.93	1.00	0.96	1.07	0.99	1.13	1.04	1.02	1.01
900°F Volatiles (%)	0.48	0.46	0.50	0.46	0.46	0.42	0.38	0.40	0.48	0.45
Liquid Parting Spray (grams)	40.0	43.1	41.0	42.0	40.0	40.2	40.8	40.7	39.9	40.9


Test FJ Detailed Process Data


APPENDIX D METHOD 25A CHARTS















































APPENDIX E GLOSSARY

Glossary

BO	Based on ().
BOS	Based on Sand.
НАР	Hazardous Air Pollutant defined by the 1990 Clean Air Act Amendment
HC as Hexane	Calculated by the summation of all area between elution of Hexane through the elution of Hexadecane. The quantity of HC is performed against a five-point calibration curve of Hexane by dividing the total area count from C6 through C16 to the area of Hexane from the initial calibration curve.
Ι	Data rejected based on data validation considerations
NA	Not Applicable
ND	Non-Detect
NT	Lab testing was not done
РОМ	Polycyclic Organic Matter (POM) including Naphthalene and other compounds that contain more than one benzene ring and have a boiling point greater than or equal to 100 degrees Celsius.
TGOC as Propane	Weighted to the detection of more volatile hydrocarbon species, beginning at C1 (methane), with results calibrated against a three-carbon alkane (propane).
VOC	Volatile Organic Compound